

UNITED STATES POSTAL SERVICE
2- TON DELIVERY TRUCK
SERVICE MAINTENANCE MANUAL



MORGAN
★ OLSON®

1801 S. Nottawa Street

Sturgis, MI 49091

Phone 800-233-4823

Fax (616-659-0499)

www.morganolson.com

www.morganolsonparts.com

INTRODUCTION

This catalog has been prepared to assist the U.S.P.S. In the maintenance of the Morgan Olson 2-Ton delivery truck. Inquiries on items found or not found in this manual may be made through the address and or phone numbers listed below.

Morgan Olson
1801 S. Nottawa
Sturgis, MI 49091
1-800-477-8287
(Customer Service/Fleet Warranty)

For Parts Ordering:
1-800-233-4823
1-616-659-0499 (Fax)
(Service Parts)

**NOTE: USE ONLY GENUINE MORGAN OLSON PARTS
USE OF NON OEM PARTS MAY VOID YOUR WARRANTY
AND/OR VIOLATE FMVSS STANDARDS**

Latest version of all documents available at;
www.morganolsonparts.com/t-usps_manuals.aspx
Access code: usps2016


Contents

| | |
|--------------------------------------|--------|
| CONTENTS & INTRODUCTION | 2-3 |
| 1. BODY TIE/DOWNS | 4 |
| 2. DOORS | |
| Side Doors | 5-9 |
| Bulkhead Door | 10 |
| Rear Door | 11-15 |
| 3. GAS SPRING | 16 |
| 4. HEATER | |
| Motor, Fan & Plenum | 17 |
| Troubleshooting | 18-29 |
| 5. HOOD | 30 |
| 6. LAMPS | 31 |
| 7. BODY PANEL REPLACEMENT AND RIVETS | 32 |
| 8. WINDSHIELD | |
| Windshield Removal and Installation | 33 |
| 9. WINDSHIELD WIPERS & MOTOR | 34 |
| 10. LIFT-GATE | 35-59 |
| 11. BACK-UP CAMERA & MONITOR | 60-68 |
| 12. REAR VIEW MIRROR SYSTEMS | 69-76 |
| 13. KEY-LESS ENTRY SYSTEM | 77-82 |
| 14. VEHICLE JACKING POINTS | 83 |
| 15. MAINTENANCE SCHEDULE (CHASSIS) | 84-93 |
| 16. ELECTRICAL WIRING DIAGRAMS | 94-115 |

Body Tie/Downs

Tie/Down Check:


The floor of the truck is fastened to bolsters that extend the length of the floor.
The lower flanges of the bolsters are mounted to the chassis frame rails.
Both sets of fasteners are torqued to specifications.
All cab and body tie/downs should be checked after 3 months and annually.



Side Door

Side Door

For smooth operation the locking mechanism should be oiled every 3 months or as needed.
Grease should also be added at the contact points of locking mechanism arm and striker.
(At opened and closed positions.)



Side Door Removal:

1. Remove screws fastening down the lower door track but leave the track in position.
2. Remove the Phillips screws and door pocket cover plate located in the upper rear corner of the door pocket.
3. Remove the 4 fasteners and the door handles (inner and outer).
4. Using a socket wrench, remove the bolts fastening the door and hanger assembly.
5. To simplify door removal, remove the grab handle located forward of the door.
*Fold side view mirror back.
6. Holding the top of the door in position, pull out on the bottom front corner of the door until it clears the body of the truck. Then tilt the top of the door down and out and remove the door.

Weather Seal Removal:

1. The forward and rear weather seals are installed simply by sliding into a mated part. To remove simply pull straight out from the top of the door or door frame. Install by feeding into the mated part and sliding into place.

Handle Mechanism Removal:

1. To remove the door handles simply remove the 4 mounting screws. Pay special attention to spacer locations. You can then remove the inside and outside handles. Remember when installing the handles, position of the spacers identical to the way they were at removal.

Door Track (Upper) Removal:

1. The upper track is mounted to the header channel. Remove the nuts, and the track. Reinstall by reversing the removal sequence.

Wear Strip (Lower) Removal:

1. Remove side door.
2. Remove existing rivets.
3. Replace wear strip and rivet in place.

Side Door Installation:

1. Tilt the top of the door in place first. Now position the bottom of the door into the lower door track, which is in position but not fastened down.
2. Put 1/8" shims between the lower door track and the wear strip.
3. Mount door to the hanger assembly.
4. Install door handles. See page 8.
5. Mount cover plate on upper rear door pocket.
6. Mount grab handle forward of door. *Re-adjust mirror.
7. For proper door adjustment see page 10.

Side Door Adjustment:

1. Loosen all nuts on the top of the slotted upper door track.
2. Loosen the 3 screws fastening down the lower door track.
3. The rear holes of the lower door track are oversized to allow for adjustment. Only the rear portion of the track can be adjusted. The forward hole of the lower track is not oversized because the door must retain its forward position to ensure proper alignment when the door is closed.
4. With the door closed and engaged in the forward strike, adjust the upper track for uniform lateral placement of the door in the forward post seal. Snug the forward bolt of the upper door track.
5. With the door open and engaged in the rear strike, the rear portion of the upper and lower tracks can be adjusted laterally to ensure proper alignment with the rear striker.
6. When the door is positioned, tighten a few of the fasteners in the upper and lower tracks. Operate the sliding door to ensure that it slides and latches properly.
7. When the door is operating properly, tighten all the remaining fasteners in the upper and lower door tracks.
8. Replace any broken studs with .25 - 20x1.00 truss head screw.
- 9 See figure 1 on the following page.

Door Latch Adjustment:

1. The door latches (strikers) and the mounting brackets provide for adjustment in a variety of directions.
2. Once the door has been adjusted to slide smoothly, then adjust the strikers for proper latch operation.




Figure 1

Bulkhead Door

Bulkhead Door:

*NOTE: Where grease is required use a **lithium based**.

1. The latch should be greased to prevent sticking. Grease should be applied at contact points of the latch and striker for smooth operation. This should be done every 3 months.



Rear Door

Rear Roll-Up Door:

1. Apply oil to the roller shafts and locking mechanism every 6 months.
2. Perform a visual inspection daily checking the lifting mechanism cables and the door strap for fraying.
3. Perform a visual inspection monthly checking for damaged parts replace immediately to prevent wear and fatigue on other components.
4. Refer to Trans global Door Company instructions for proper rear door spring adjustment and/or replacement.




Rear Door





ROLL-UP DOOR SERIAL NUMBER LOCATION

WHEN ORDERING PARTS FOR ROLL-UP DOORS,
PLEASE PROVIDE THE FOLLOWING INFORMATION.
THE SERIAL NUMBER LOCATED ON THE INTERIOR TOP PANEL ROADSIDE EDGE.
THE LENGTH AND HEIGHT OF THE DOOR PANEL(S) TO BE ORDERED.

IN THE EVENT OF A DAMAGED, NU-READABLE OR MISSING SERIAL NUMBER,
PLEASE TRY TO PROVIDE THE COMPOSITION DETAILS OF THE DOOR PANEL.
(PLASTIC COATED, ALUMINUM CLAD, PLYWOOD, ETC.)



Rear Door




Rear Door

| Attached Hardware | | |
|-------------------|-----------------|---|
| ITEM | Part # | Description (rivet count) |
| a | TG-70001-.25 | Aluminum Top Panel Seal W/ Extended Lip (4- 5/8" SS) |
| b | TG-6944 | Top Closure Complete (8 - 3/4" SS) |
| c | TG-HD1209-A | HD End Hinge (12- 11/16", 12- 13/16") |
| d | TG-HD15 | Center Hinge (12- 11/16", 12- 13/16") |
| e | TG-1715 | Lift Handle Black (2- 5/8" SS) |
| f | TG-4004 | Cable Anchor Brkt (4 - 5/8" SS) |
| g | TG-9723-12-2 | 12" Looped Pull Strap, Black (2- 1/8" SS) |
| h | TG-5600-2.5-6-1 | 3 Stud Bottom Fixture .5" & .25" Composite Door (6 - 5/8" SS) |
| i | TG-EGPSESSNL-88 | D-Ring, non-locking Handle w/ extended shaft, R/Door |
| j | TG-69011 | Best Cylinder Lock Cylinder, R/Door |
| k | TG-69011-EXT | Best Cylinder Lock Cylinder Collar, .25" |
| l | TG-69007 | Cam for Best Cylinder |
| m | TG-70472-1 | 2-PT End Latch CS |
| n | TG-70472-2 | 2-PT End Latch RS |
| o | TG-70194.01 | Lock Cover Base - End |
| p | TG-39545 | Cable Assem 2-PT Lock with (2) Stops and Washer |
| r | TG-70194.08 | Latch Base Center - .91" Off, D-Ring .25" & .5"Comp, 1" Track |
| s | TG-69959 | Center Control Complete |
| t | TG-70497-.25 | .25" Composite Bottom Seal 4-PT 98.25" Length (pcs) Rubber |
| u | TG-61192-85 | 85" long Bottom Angle for .25" Composite (4 - 5/8" SS) |

| Packaged Loose Hardware | | |
|-------------------------|--------------|---|
| ITEM | Part # | Description |
| v | TG-61174 | 1" Steel Rollers |
| w | TG-80020 | Spacer Washers |
| x | TG-909514 | 95" 7x19 Stainless Steel Cable 1/4" Metal Eye |
| y | TG-61026 | 1/4" x 1" Cable Anchor Pin |
| z | TG-80401-316 | 3/32" x 1" Cotter Pins |
| (1pr) | TG-5377-80 | Push In Side Seal - Cut to 75 1/2" |


| Part # | Description (rivet count) |
|----------------|---|
| TG-87000-11 | 1/4" x 11/16" Aluminum Buck Rivets |
| TG-87000-13 | 1/4" x 13/16" Aluminum Buck Rivets |
| TG-89291-26 | 5/8" Stainless Steel Rivets |
| TG-89291-28 | 3/4" Stainless Steel Rivets |
| TG-89291-30 | 7/8" Stainless Steel Rivets |
| TG-89186-27-SS | 1/4 - 20 x 3/4" SS Carriage Bolt |
| TG-89231-3 | 1/4 - 20 Nylok |
| TG-89186-26 | 12-24 X 1/2" Brass FSLMC (Fastenal # 1175648) For Best Cylinder |




| Counter Balance Parts | | |
|-----------------------|---------------------|--|
| Note # | Part # | Description |
| pp | TG-99987 | .95 X 11 Ga X 87" Tube (cut to 68 1/4") |
| qq | TG-51065-.192X22.25 | Spring Assembly .192 x 1 3/4" x 22.25" (RH) Coated |
| rr | TG-51036-2 | 4 7/8 x 5 Right Hand Anchor Bracket |
| ss | TG-59157-4 | Cable Drum RH |
| tt | TG-59157-3 | Cable Drum LH |
| | TG-51078 | Silencer Boot |

| Counter Balance Complete Assembly | | |
|-----------------------------------|------------------------------|--|
| Note # | Part # | Description |
| | TG-59174-.192X22.25X62 Shift | CB Assem w/ .192 x 1 3/4" x 22.25" Spring w/ 62" |

Rear Door



| Horizontal Track | | |
|------------------|-----------------------------|--|
| Part # | Description | |
| kk | TG-49622-1-47106270 | Horizontal Track - STD LH / CS (Morgan Olson # 47106270) |
| ll | TG-49622-2-47106270 (Shown) | Horizontal Track - STD LH / CS (Morgan Olson # 47106270) |
| mm | TG-69353 | Head Protector Yellow |
| nn | TG-89231-2 | 1/4" - 20 Kep Nut |
| oo | TG-89186-5 | 1/4" x 1 3/4" Hex Head Bolt |



| Vertical Track | | |
|----------------|-----------------------------|--|
| Part # | Description | |
| aa | TG-49192-1-47106270 | 1" Vertical Track Asm. - LH/CS (Morgan Olson # 47106270) |
| bb | TG-49192-2-47106270 (Shown) | 1" Vertical Track Asm. - RH/RS (Morgan Olson # 47106270) |
| cc | TG-59304-2 (Shown) | 4 7/8 x 4" Right Anchor Bracket - Clipped |
| dd | TG-59304-1 | 4 7/8 x 4" Left Anchor Bracket - Clipped |
| ee | TG-51038 | Bearing Assembly |
| ff | TG-89186-4 | 3/8" x 1" Hex Head Bolt |
| gg | TG-89231-4 | 3/8" - 18 Kep Nut |
| hh | TG-69953-1 | Catch Mounting Plate - LH (CS) |
| ii | TG-69953-2 (Shown) | Catch Mounting Plate - RH (RS) |
| jj | TG-69951 | Lock Catch |

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

Gas Spring

Gas Spring Replacement:

1. With the hood safely propped, remove the upper and lower retainer clips. Once the clips have been removed a slight tap will remove the gas spring from the ball studs.
2. For safety reasons, when replacing the gas springs use only Morgan Olson OEM replacement parts.



Heater

Motor and Fan Replacement:

1. The heater is mounted to the right hand dash panel.
2. With the power to the motor off, disconnect the motor leads.
3. Remove motor mounting screws. Remove the motor and the impeller wheel.
4. Take out the set screw to remove the impeller wheel (squirrel cage).
5. For installation, reverse the sequence.



Plenum

Plenum Replacement:

1. Detach air inlet hose from plenum.
2. Disconnect wiring harness at heater box and instrument panel harness.
3. Remove fasteners from plenum diffuser (located on top of the windshield rail).
4. Remove the fasteners located on top of the windshield rail.
5. Installation sequence is opposite of removal.


SERVICING AND TROUBLESHOOTING

A/C-HEATER-DEFROSTER

CONTROL PANEL OPERATION

BLOWER CONTROL The BLOWER CONTROL provides three choices of air velocity in every operating mode. When the blower switch knob is rotated fully counterclockwise (with the knob indicator pointing straight up) the blower is turned OFF. Rotating the knob clockwise will progressively increase the air velocity.

TEMPERATURE CONTROL The TEMPERATURE CONTROL KNOB controls the discharge air temperature in all operating modes. Turning the knob to the right (red zone) increases temperature; turning the knob to the left (blue zone) decreases air temperature. Temperature control is achieved through the regulation of engine coolant through the heater coil.



MODE SELECTION SWITCH

- Dash** When this mode is selected, all air is discharged through the dash louvers.
- Bi-Level** With this setting, air is discharged through the dash louvers and onto the floorboard. This is the ideal mode for rapid warm-up in cold weather.
- Floor** This mode will direct all air to the floorboard. This mode is most frequently selected when heating is required.
- Floor/Windshield** When this mode is selected, air is discharged onto the floorboard and onto the windshield.
- Defrost/De-fog** This mode will direct most of the air to the windshield and provides for rapid defrosting of the outside of the windshield and defogging of the inside surface. A reduced volume of air is provided for floor heating.


A/C CONTROL

The blue rocker switch will engage the A/C system compressor when the upper edge of the switch is pressed. Pressing the lower side of the switch will turn the A/C compressor off.

AIR SOURCE CONTROL

The green rocker switch permits the driver to re-circulate cabin air or introduce outside air into the HVAC system. Pressing the upper edge of the green switch will block outside air and permit the re-circulation of inside air. Pressing the lower edge of the switch will introduce outside air.

WIRING DIAGRAM



USPS 2 Ton Delivery Vehicle 2016 - 2018 Models

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

TROUBLESHOOTING

SECTION A: AIRFLOW PROBLEMS

PROBLEM A-1, No air flow, blower does not operate

POSSIBLE CAUSE #1 ~ Faulty Blower Motor


CORRECTIVE ACTION ~ With ignition turned ON, unplug the 2-pin connector at the blower motor. Check the orange wire for +12 volts and the white wire for a fully grounded circuit. If power is present and the circuit grounded, remove the motor and wheel from the blower housing. Inspect for any evidence of entrapped debris or a broken blower wheel that might have prevented rotation. If no such evidence exists, replace the blower motor.

POSSIBLE CAUSE #2 ~ Blown fuse due to short in wire harness

CORRECTIVE ACTION ~ Refer to the HVAC Wiring Diagram and the Chassis Manufacturer's wiring information. Trace the entire HVAC wiring for an electrical short. Replace or repair as required.

POSSIBLE CAUSE #3 ~ Defective Blower Switch


CORRECTIVE ACTION ~ Refer to the Blower Switch Continuity Diagram and check the blower switch for continuity through the switch in all four switch positions. Replace the blower switch as required.



PROBLEM A-2, Blower operates, but not in all blower switch settings

POSSIBLE CAUSE #1 ~ Blower resistor failure.

CORRECTIVE ACTION ~ If the blower operates only on the highest blower speed (blower switch rotated fully clock-wise), the blower resistor has, most likely, failed. [Hint: The resistor is bypassed when the highest blower speed is selected.] Refer to the Blower Motor Resistor illustration (below); remove the three-wire connector from the resistor. Check for electrical continuity between terminal 1 and 2. If an open circuit exists between 1 and 2, the thermal limiter has blown and it will be necessary to replace the resistor. [Note: A failed resistor is often the results of a problem with the blower motor. Make sure that the blower motor is fully operable and is not bound in any sort of way by a broken blower wheel or entrapped debris within the blower housing.]



POSSIBLE CAUSE #2 ~ High-blower relay failure

CORRECTIVE ACTION ~ If the blower operates in all speed selections except for the highest selection there is a possibility that the high-blower relay has failed. [Note: The high-blower relay is activated when the highest blower speed is selected. The relay extends the life of the blower switch and insures the highest voltage for the motor.] Remove the relay and test for an open circuit across terminals 85 and 86. If the circuit is open, replace the relay.

PROBLEM A-3 ~ Air does not flow from the selected outlets

POSSIBLE CAUSE #1 ~ Plenum directional doors obstructed

CORRECTIVE ACTION ~ Examine the air distribution Plenum for any possible obstruction that might have become entrapped internally. Refer to the Mode Selection & Servo Motor Position Correlation Diagram for the position of each of the doors in every mode selection. The output shafts of the servo motors can be observed, externally, as they move through their approximate 100 degrees of travel. Also, the doors can be physically touched by removing the 5" flexible inlet duct and reaching into the plenum's air intake. If a physical obstruction is suspected, it may be necessary to remove the plenum. [Note: Access to the plenum's mounting hardware will require removal of the defroster ducts from atop the dash.]


CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION


MODE SELECTION & SERVO MOTOR POSITION CORRELATION DIAGRAM



| CONTROL PANEL MODE SELECTION | SERVO MOTOR | | AIR DISTRIBUTION |
|---------------------------------|---------------|------------------------|---------------------------|
| | FLOOR/DEFROST | DASH/ FLOOR-DEFROST | |
| | | | |
| | B | F | DASH LOUVERS |
| | A | E | DASH LOUVERS AND FLOOR |
| | A | D | FLOOR |
| | B | D | FLOOR AND WINDSHIELD |
| | C | D | WINDSHIELD |

POSSIBLE CAUSE #2 ~ Servo motor failure

CORRECTIVE ACTION ~ If servo motor failure is suspected, the first step is to confirm that the electrical connections at the servo motors are delivering the correct signal to the motors. With the ignition switch turned to **Accessory**, unplug each of the servo connectors and test according to the information in the **Electrical Connection To Plenum Servo Motors Diagram**. If the electrical check is in agreement with the **Diagram** and if the directional doors are not obstructed, the likely problem is a failed servo motor. Replace servo motor as required.



POSSIBLE CAUSE #3 ~ Control Panel Selector Switch is defective

CORRECTIVE ACTION ~ With the ignition turned to Accessory, unplug each of the connectors from the Plenum servo motors and test according to the information in the *Electrical Connection To Plenum Servo Motors Diagram*. If the test fails to find agreement with the *Diagram* there is a good possibility that the Mode Selection Switch at the control panel is defective. Replace the Mode Selection Switch.


SECTION B: TEMPERATURE CONTROL PROBLEMS

PROBLEM B-1, Air temperature cannot be controlled

POSSIBLE CAUSE #1 ~ Water valve not operating

CORRECTIVE ACTION ~ Valve may not be receiving a signal from control panel, or valve is defective. Disconnect the electrical connector from the valve. With the ignition switch turned to **Accessory**, check for the presence of 12 volts between the red wire (+12 V) and the white wire (ground) as noted in the *Water Valve Electrical Diagram*. The yellow/red signal wire will provide +12 V (full cold position) dropping to zero volts (full hot position) as the temperature control knob is rotated clockwise. If the condition at the connector is in agreement with the *Diagram*, proceed as follows:

- Step 1 Disconnect the water valve from the 5/8" heater hoses,
- Step 2 Carefully inspect the four small terminal pins on the motor, make sure that they are not damaged,
- Step 2 Reconnect the valve to the electrical connector,
- Step 3 Rotate the Temperature Control Knob and watch for any response from the valve,
- Step 4 If no valve rotation is observed, replace the valve.



POSSIBLE CAUSE #2 ~ Water valve not electrically connected

CORRECTIVE ACTION ~ Disconnect the electrical connector from the valve. With the ignition switch turned to **Accessory**, check for the presence of 12 volts between the red wire (+12 V) and the white wire (ground) as noted in the *Water Valve Electrical Diagram*. The yellow/red signal wire will provide +12 V (full cold position) dropping to zero volts (full hot position) as the temperature control knob is rotated clockwise. If none of these conditions exist, refer to the *Wiring Diagram* and examine the system's wire harness for any loss of continuity. Repair as required.

PROBLEM B-2, A/C system not providing cool air

POSSIBLE CAUSE #1 ~ Loss of refrigerant

CORRECTIVE ACTION ~ Verify the presence of 1.75 pounds of refrigerant R134a. If the AC system is either partially low, or completely empty, a search will be required for leakage. Replace and repair as required.

POSSIBLE CAUSE #2 ~ Compressor not engaged

CORRECTIVE ACTION ~ Confirm that the system is fully charged. With the ignition switch turned to **Accessory**, the blower switch turned to the highest speed and the AC (blue) rocker switch engaged, proceed as follows:

- Step 1: Check for the presence of 12 volts at the compressor. If yes, make certain that the compressor clutch is fully grounded. If the ground circuit is intact, the compressor clutch has, most likely, failed and requires replacement.
- Step 2: If no voltage is present at the compressor clutch, refer to the *Wiring Diagram* and check for voltage at each of the system pressure switches. [Note: The low pressure switch is located on the suction hose near the firewall and opens on a pressure drop to 8 psi. The binary (high/low) pressure switch is located on the liquid hose near the receiver/drier and opens on a pressure rise to approximately 400 psi and a pressure drop to 28 psi.] With the system fully charged, there should be continuity through both switches. Replace as required.
- Step 3: If no voltage is present at the pressure switches, check for voltage at the thermostat (located externally on the HVAC housing). Assuming that the evaporator coil is fully warmed to ambient conditions, the thermostat should be a closed circuit. [Note: The thermostat circuit opens when the evaporator coil surface temperature drops below 32 degrees F; this action prevents the accumulation of ice on the evaporator coil surface.] If the thermostat presents an open circuit, replacement is required. Thermostat replacement requires the complete removal and disassembly of the HVAC housing. When replacing thermostat, take special care to not kink the capillary tube. Also, install the new capillary tube in the same location as the original.

POSSIBLE CAUSE #3 ~ Perceived lack of cooling due to extreme conditions

CORRECTIVE ACTION ~ Note that extremely high humidity can reduce the effectiveness of the evaporator. The *Ambient Temperature vs. Relative Humidity Chart* (below) illustrates how very high humidity can raise the louver temperatures. This test is best performed with the doors and windows open, the blower turned to the highest speed and the AC system fully engaged. Run the engine at 1500 rpm and allow time for the system to stabilize. Measure the discharge air temperature at one of the dash louvers and compare to the *Chart*.

| | | AMBIENT TEMPERATURE | | | | |
|---|------|---------------------|----|----|----|-----|
| RELATIVE HUMIDITY | | 60 | 70 | 80 | 90 | 100 |
| | 10% | * | * | 38 | 48 | 58 |
| | 20% | * | * | 39 | 49 | 59 |
| | 30% | * | * | 45 | 49 | 63 |
| | 40% | * | 39 | 48 | 53 | 68 |
| | 50% | * | 42 | 53 | 57 | 73 |
| | 60% | * | 46 | 57 | 60 | 79 |
| | 70% | * | 49 | 61 | 67 | 82 |
| | 80% | 39 | 52 | 64 | 71 | 85 |
| | 90% | 42 | 55 | 68 | 74 | 88 |
| | 100% | 46 | 57 | 71 | 77 | 90 |
| * VALUES IN THE SHADED AREA SUBJECT TO FLUCTUATION DUE TO CYCLING OF THE COMPRESSOR | | | | | | |

SECTION C: DIAGNOSIS OF REFRIGERANT RELATED PROBLEMS


Consult the following *Refrigerant System Evaluation* chart (below) for a list of refrigerant related symptoms and their recommended resolution:

REFRIGERANT SYSTEM EVALUATION

| SYMPTOM | LOW-SIDE GAUGE | HIGH-SIDE GAUGE | DIAGNOSIS | CORRECTION |
|--|---|-------------------------------------|--|---|
| AIR SLIGHTLY COOL | NORMAL | NORMAL | AIR & MOISTURE IN SYSTEM | REPLACE RECEIVER/DRIVER RECHARGE |
| SYSTEM OPERATED NORMALLY FOR A SHORT PERIOD, BUT AIR WARMS AS LOW SIDE DROPS TO ZERO | INITIALLY NORMAL | INITIALLY NORMAL | EXCESS MOISTURE IN SYSTEM TURNING TO ICE WITHIN EXPANSION VALVE | REPLACE RECEIVER/DRIVER, RECHARGE |
| SYSTEM OPERATED NORMALLY, BUT AIR FLOW GRADUALLY DECREASES | INITIALLY NORMAL, BUT DROPS AS AIR FLOW DECREASES | NORMAL, BUT DROPS AS AIR FLOW DROPS | THERMOSTAT FAILURE ALLOWING SURFACE OF EVAPORATOR COIL TO FREEZE | REPLACE THERMOSTAT |
| POOR COOLING | LOW | LOW | LOW REFRIGERANT CHARGE | REPAIR SYSTEM LEAKS, RECHARGE |
| POOR COOLING, ICE FORMING ON SURFACE OF EXPANSION VALVE | LOW | LOW | EXPANSION VALVE STUCK IN CLOSED POSITION | REPLACE EXPANSION VALVE, RECHARGE |
| POOR COOLING, SWEATING MAY APPEAR ON HIGH-SIDE COMPONENTS | LOW | LOW | RESTRICTED REFRIGERANT FLOW ON HIGH SIDE | REPAIR/REPLACE DEFECTIVE HIGH SIDE COMPONENTS, RECHARGE |
| POOR COOLING NOISY COMPRESSOR | LOW | LOW | COMPRESSOR MALFUNCTION | REPLACE COMPRESSOR RECHARGE |
| POOR COOLING HIGH SIDE LINES HOT | HIGH | HIGH | SYSTEM OVER CHARGE | RECHARGE SYSTEM (1.75 #R134A) |
| POOR COOLING HIGH SIDE LINES HOT | HIGH | HIGH | POOR CONDENSING | INSPECT CONDENSER FOR OBSTRUCTIONS THAT COULD REDUCE AIR FLOW |
| POOR COOLING | HIGH | HIGH | EXPANSION VALVE STUCK OPEN | REPLACE EXPANSION VALVE, RECHARGE |

ADDITIONAL SERVICABLE ITEMS

| ITEM # | PART NUMBER | DESCRIPTION |
|--------|-------------|--|
| 1 | 20-03102 | #6 HOSE ASSEMBLY, RECEIVER/DRIER TO EVAPORATOR |
| 2 | 20-03103 | #6 HOSE ASSEMBLY, CONDENSER TO RECEIVER/DRIER |
| 3 | 20-03104 | #8 HOSE ASSEMBLY, COMPRESSOR TO CONDENSER |
| 4 | 20-03106 | #12 HOSE ASSEMBLY, EVAPORATOR TO COMPRESSOR |
| 5 | 07-01231 | RECEIVER/DRIER |
| 6 | 55-05341 | RECEIVER/DRIER MOUNTING BRACKET |
| 7 | 44-00196 | RELAY |
| 8 | 12-02274 | WIRE HARNESS (FOR BINARY PRESSURE SWITCH) |
| 9 | 11-00644 | BINARY PRESSURE SWITCH |
| 10 | 11-00576 | LOW PRESSURE SWITCH |
| 11 | 70-08468 | WATER VALVE |




CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

| ITEM # | PART # | DESCRIPTION | QTY | UNIT |
|--------|-----------|---|-----|------|
| 1 | 555001107 | HEATER CORE ASSEMBLY | 1 | EA |
| 2 | 47008760 | HEATER COIL W/GASKET & CLAMP | 1 | EA |
| 3 | 47008753 | DOOR W/SEAL | 1 | EA |
| 4 | 47008754 | BLOWER HOUSING | 1 | EA |
| 5 | 47008755 | BLOWER ADAPTER | 1 | EA |
| 6 | 47008732 | RESISTER CAGE | 1 | EA |
| 7 | 47008357 | RESISTER | 1 | EA |
| 8 | 47008756 | BLOWER MOTOR | 1 | EA |
| 9 | 47008757 | BLOWER WHEEL | 1 | EA |
| 10 | 47008730 | VENT TUBE | 1 | EA |
| 11 | 47008731 | VENT TUBE ADAPTER | 1 | EA |
| 12 | 47008716 | RELAY | 1 | EA |
| 13 | 47008758 | HARNESS | 1 | EA |
| 14 | 47008580 | FORMED HEATER HOSE | 2 | EA |
| 15 | 555002053 | VALVE WATER | 1 | EA |
| 16 | 105080401 | PLATE MOUNTING FOOT DUMP AL .07X4.25X5.53 | 1 | EA |
| 17 | 090080401 | DUCT FT DUMP SPECIAL | 1 | EA |
| 18 | 21-01201 | GASKET - PART OF HEATER ASSEMBLY | 1 | EA |
| 19 | 21-01202 | GASKET - PART OF HEATER ASSEMBLY | 1 | EA |
| 20 | 555001416 | CONTROL PANEL ASSEMBLY | 1 | EA |
| 21 | 47008706 | KNOB | 2 | EA |
| 22 | 47008735 | KNOB | 1 | EA |
| 23 | 47008707 | DECAL | 1 | EA |
| 24 | 47008708 | LIGHT PANEL | 1 | EA |
| 25 | 47008709 | CONTROL SUB PANEL | 1 | EA |
| 26 | 47008700 | BLOWER SWITCH | 1 | EA |
| 27 | 47008710 | POTENTIOMETER SWITCH | 2 | EA |
| 28 | 47008711 | HARNESS ILLUMINATION W/BULBS | 1 | EA |
| 29 | 47008712 | HARNESS BLOWER MOTOR | 1 | EA |
| 30 | 555001721 | DEFROST DUCT CURBSIDE METAL | 1 | EA |
| 31 | 555001722 | DEFROST DUCT ROADSIDE METAL | 1 | EA |
| 32 | 093080400 | HOLD DOWN PLATE DEFROSTER DUCTS | 4 | EA |
| 33 | 555001524 | HOSE DEFROSTER 2.5X30 | 1 | EA |
| 34 | 555001525 | HOSE DEFROSTER 2.5X38 (2x DEFROSTER / 1xFOOT DUMP) | 3 | EA |
| 35 | 555002003 | COLLAR FRESH AIR INTAKE | 1 | EA |
| 36 | 555001715 | LOUVER BALL | 6 | EA |
| 37 | 555002007 | PLENUM FRESH AIR SIDE WALL (DRAIN HOSE - 555002008) | 1 | EA |
| 38 | 107027405 | BRACKET HEATER VENT | 1 | EA |
| 39 | 555001533 | HOSE BLOWER HEATER/DEFROSTER 5"X7.5" | 1 | EA |
| 40 | 005780402 | MOUNTING PLATE | 1 | EA |
| 41 | 002080400 | BRACKET HEATER CONTROL AL .102X3X11.67 | 1 | EA |
| 42 | 555001321 | DUCT HVAC | 1 | EA |
| 43 | 555001523 | HOSE DEFROSTER 2.5X16 | 1 | EA |
| 44 | 47008017 | CONNECTOR STRAIGHT .62ID BLACK NYLON | 2 | EA |
| NS | 555002164 | CAP DEFROSTER PORT 2.5IN DIA ROUND | 2 | EA |



HOOD

Hood Removal:

1. For removal of the gas springs. See page 14.
2. Disconnect wire harness plug connections.
3. Remove the 4 bolts tying the left and right hinge assemblies to the body of the truck.
4. Disconnect hood prop.
5. At this point the hood can be removed.

Hood Installation:


1. Before installation fasten hinge assemblies to hood assembly. Now using the original 4 fasteners install the completed assembly.
2. For installation of the gas springs, see page 14.
3. Reconnect all wiring.
4. Reconnect hood prop.

Hinge Replacement:

1. To replace hood hinge, remove three bolts attached to hood assembly.
2. Remove two bolts attached to windshield rail.
3. Slide hinge out to the side of the truck.
4. To replace hinge, install in reverse order.

Hood Stop Adjustment:

1. The stops that support the hood should be adjusted if the hood ever comes into contact with the cab skirts. The stop bracket is slotted to allow for vertical adjustment. Adjust brackets so that hood seats evenly and does not come into contact with cab skirts.



LAMPS

Headlight Replacement:

1. Remove screws and trim from around headlight.
2. Remove headlight.
3. Remove wiring plug from back of headlight.
4. Replace headlight.
5. For installation reverse removal sequence.

Tail, Turn Backup and Marker Lamp Replacement:

1. Push tail, turn back-up lamp into rubber grommet and use a small flat head screw driver and pry lamp from rubber grommet.
2. Remove wiring plug from back of lamp.
3. Install new lamp by reconnecting wiring plug to new lamp and pushing lamp into rubber grommet until properly seated.

Clearance Marker and ICC Light Replacement:

1. From inside, unplug the lamp, push lamp out of the grommet. To replace, from the outside push the lamp into grommet. Some lubrication helps installation. Install so the marking is towards the top. Hook up wiring taking care to match the polarity.




BODY PANEL REPLACEMENTS & RIVETS

Body Panel Replacement:

1. When replacing exterior body panels, remove rivets following procedures outlined below.
2. Apply sealant to new panel as required.
3. Install new panel in reverse order.

Removing A Rivet:

1. When removing an existing rivet, place the drill bit on the small dot in the center of the rivet head. Twist the drill chuck by hand to enlarge the small dot. This will prevent the drill from slipping.
2. *Never drill completely through the rivet or you risk enlarging the hole which can weaken the bond when re-fastened. Drill into the center of the rivet head. With drill turned off but still in place, move it horizontally and vertically until the head of the rivet comes off. Use an awl and a mallet to tap the rivet shank out.
3. If you accidentally drill through the material, see the following instructions.



Re-Riveting:

1. When replacing new panels, use .19 diameter rivets. The correct length rivet will measure .25-.38 beyond the material being joined. (See diagram below)
2. When ever rivets are removed there is always some enlargement to the hole. To ensure the strength of the new bond, follow these steps.
3. Drill the hole out to .25" diameter. If the hole is already .25" diameter then drill it out to .28" diameter and use a .25" bolt and nut, otherwise continue to the next step.
4. Rivet the parts using a .25" rivet. The correct length rivet will measure .25-.38 beyond the material being joined.

NOTE: As the vehicle ages, it is not uncommon for some rivets to loosen. This can often be detected by a black ring (aluminum oxide) around the head of the rivet. If this happens replace the rivet. See Re-Riveting.




WINDSHIELD REPLACEMENT

Windshield Removal:

1. Special tools are required for windshield removal. Glass and Bead Tools.
2. A soap and water solution should be applied around the rubber seal. This will allow the tools to move smoothly when in contact with the rubber seal.
3. Using the glass tool pry between the windshield and the rubber seal. This will enable you to pry the glass from the seal. Leaving the tool in position work your way around the glass. Pushing the top corners of the windshield from inside the truck will get the removal process started.

NOTE: For safety reasons this task should be performed by two people.




Windshield Installation:

1. Special tools are required for windshield removal. Glass and Bead Tools.
2. Insert rubber seal into window frame.
3. A soap and water solution should be applied around the rubber seal. This will allow the tools to move smoothly when in contact with the rubber seal.
4. Position the bottom of the windshield in place first. Using the glass tool pry the lip on the seal out to allow the windshield to seat in the seal properly. Work your way around the window until it is seated properly.
5. Do this around the whole windshield until the windshield seats properly in the frame.

WINDSHIELD WIPERS & MOTOR

Windshield Wipers and Wiper Drive Assembly:

1. Replace the wiper arm by removing the acorn nut and washer hose. To insure proper placement of the new wiper, mark the position of the old wiper arm before removing.
2. Reinstall in reverse order.



LIFT-GATE

If anyone observes improper installation, improper operation, or damage, they should immediately contact a qualified person for assistance and correction. We strongly urge anyone that has any questions or doubts as to the installation, condition, use, operation, maintenance or repair of the lift-gate to contact us at Waltco where we have qualified personnel that will be happy to assist you. Telephone numbers and addresses of these locations are listed in the Owner's Manual and Installation Instructions.

INSTALLATION

Waltco lift-gates should only be installed by those with sufficient basic skills to understand the installation and operation of the lift-gate, along with the equipment on which the lift-gate is being installed. Waltco's installation instructions are not intended to give rationale for all the instructions that are given; however, it is the intent of these instructions to give the installer both the operations and what we believe to be the most desirable sequence of implementing these operations. These instructions can in no way expand into an area where they will replace a qualified person, or clear thinking and a basic knowledge that must be possessed by the installer.

It has been our experience that a knowledgeable journeyman following these instructions and observing the operation of the lift-gate will have a sufficient comprehension of the lift-gate to enable this person to troubleshoot and correct all normal problems that may be encountered. Failure to follow the installation instructions, adjustments and mounting dimensions may result in improper and unsafe operation of the lift-gate. Unauthorized alterations of the lift-gate can cause an undesirable and dangerous condition.

OWNER'S MANUAL

The Waltco Owner's Manual is intended to act as a guide for operation and routine maintenance but is no way intended to encourage usage or repair of the lift-gate by those who are not qualified to do so.

The contents of the owner's manual include, but are not limited to general operation instructions, routine lubrication, parts lists, and an outline of things that should be checked but may not be obvious to those not technically qualified. This manual assumes the lift-gate is properly installed, undamaged and operates correctly. Improper installation, improper operation, or damage should be immediately corrected by a qualified person.

INSPECTION

As part of the regular inspection of a lift-gate and after damage or suspicion of an overload, inspect for wear or structural damage and make necessary repairs or replacements. Check all structural components and their attachment to the lift-gate for cracked welds, loose fasteners, wear and part deformation. Check cylinder and hose for leaks. Inspections and repairs should be made by a qualified mechanic.

REPLACEMENT PARTS

Use only Waltco original equipment replacement parts. Components of other lift-gate manufacturers may outwardly appear to be the same but are not interchangeable with Waltco products. Waltco components are specifically designed for safety requirements, reliability and compatibility with our products. Refer to your Waltco parts manual when ordering parts. NOTE: When ordering, give model and serial number of lift-gate.

DECALS

It is important that every vehicle that has a WALTCO Lift gate have legible DECALS clearly posted on the vehicle and an OWNER'S MANUAL in the vehicle at all times as a guide for proper operation and maintenance.

SAFETY INFORMATION



WARNING

- Read, understand, and follow all of the warning listed below.
- Failure to follow these warning could result in severe personal injury or death.
- Read and understand the Owner’s Manual, all decals and warning on lift-gate before operating lift-gate.
 - Do not operate lift-gate without a thorough knowledge and understanding of the operation of the lift-gate.
 - Lift gate hazards can result in crushing or falling.
 - This lift-gate is designed for loading and unloading of cargo. If personnel are required to ride lift-gate, observe and familiarize yourself with the lift-gate operation, decals and manuals. Ensure stable footing at all times.
 - Do not ride lift-gate with unstable loads.
 - Wheeled loads must be properly retained from rolling.
 - Tall, high center of gravity loads must be retained from falling over.
 - Never overload lift-gate: Load platform as close to the vehicle, and towards the middle of the platform as possible. Refer to owner’s manual and capacity decal of lift-gate for maximum load and load placement.
 - Keep hands and feet clear of all potential pinch points.
 - Never use lift-gate if it makes any unusual noise, has unusual vibration, raises or lowers unevenly, or fails to operate smoothly.
☐ Never use lift-gate if it shows any signs of structural damage such as cracked welds, bent or distorted members.
 - Do not attempt any repairs unless you are qualified to do so. Care should be taken when work is performed on a disabled lift-gate located near moving traffic. When possible the vehicle should be moved away from traffic areas for repair. Precautionary measures should be taken to ensure personal safety including those recommended in Federal Motor Vehicle Safety Standards 571.125.
 - When welding to lift-gate, or lift-gate components, take all necessary safety precautions, including using respiratory protection and other pertinent personal protective gear when welding harmful materials.
 - All protective covers, guards, and safety devices must be in place and access doors closed before operating lift-gate.
 - Do not allow anyone to stand in, or near area, in which Platform will open and close before opening or closing Platform.
 - Do not allow anyone to stand near the Platform where a falling load could land on them.
 - Platform is always to be properly stored and secured for transit. See the Owner’s Manual for details.
 - Take care to retain cargo during transit for lift-gate Platforms which function as the tailgate or door of the cargo area. Small objects can fall through the space between the vehicle and the folded Platform.
 - A Lock-Out device or Shut-Off Switch should always be used to prevent unauthorized use of lift-gate.
 - For lift-gates with Runners, never use lift-gate if Runners do not travel freely and smoothly.
 - For lift-gates with Roller Lifting Chain, the Chain should be replaced every (5) five years or 15,000 cycles, whichever comes first. Replace only with Waltco approved Roller Chain.
 - Never transfer loads which exceed lifting capacity on or over any part of the Platform unless the lift-gate is equipped with a special reinforced Platform and Platform Support Bars for use when the Platform is used as loading ramp (dock board). Refer to the “Using Platform as a loading ramp” Chapter in the Operation Instructions of the BZ/RZ series Owner’s Manual.
 - For lift-gates equipped with Trailer Hitches, never exceed the rated capacity of the hitch. Do not exceed the vehicle’s weight rating. Refer to the vehicle’s Owner’s Manual.
 - Vehicle must comply with all state and federal standards.
 - Follow the “Maintenance Guide” chapter in the Owner’s Manual.



SAFETY INFORMATION



WARNING

- Lift-gates with Tilt Function
- Proper use of the Control Switches is of extreme importance.
 - Improper use of Tilt Switch could cause load to fall from the Platform or damage the lift-gate.
 - Platform should be in a generally horizontal position when raising or lowering with a load.
 - In any tilt position, the Platform may vary from level while raising or lowering the Platform.
- Lift-gates equipped with spring operated Cam Closer
- Replace Cam Release Spring every five (5) years or 15,000 cycles, whichever comes first.
- RGL-Series Lift-gates
- Make certain Platform Brake mechanisms are operating properly.
 - The Runners are always to remain powered up against the Up stops Pins when in transit.
 - Inspect Cables every three (3) months or 750 cycles, whichever comes first. Cables must be replaced if they show signs of wear, distortion, kinking or if any broken wires are visible.
 - Replace cables every five (5) years or 10,000 cycles, whichever comes first.

SIGNAL WORDS

| | |
|---|---|
| <p>WARNING</p> <p>Indicates a potentially hazardous situation, which if not avoided, could result in death or serious injury. Black letters on an orange background</p> |  <p>WARNING</p> |
| <p>CAUTION</p> <p>Indicates a potentially hazardous situation, which if not avoided, may result in minor or moderate injury. May also be used to alert against unsafe practices.</p> |  <p>CAUTION</p> |
| <p>NOTICE</p> <p>Indicates a potentially hazardous situation, which if not avoided, may result in property damage.</p> | <p>NOTICE</p> |

WALTCO Warranty Policy

WALTCO warrants its products free of defects in materials and workmanship.

WALTCO will replace components found defective during the warranty period. Labor will be reimbursed according to our flat rate labor schedule at the prevailing shop rate.

Contact our Sales or Warranty departments for the warranty period of your model or for information regarding our flat rate labor schedule.

WALTCO Warranty Claim Procedure

For consideration, all claims must be received within 30 days of repair and include the following information:

- Liftgate Serial Number
- Description of problem and corrective actions
- Itemization of the labor charge to include the number of hours and labor rate

Replacement warranty parts can be obtained by contacting Waltco's Parts Department. Parts must be returned for inspection when requested.

Exclusions:

Waltco's warranty does not include reimbursement for service calls, vehicle rental, towing, travel time, fabrication of parts available from WALTCO, damage from misuse or abuse, negligence, accidents, alteration, loss of income or overtime expense, oil, or normal wear.

Diagnosis and troubleshooting time are included in the flat rate labor times.

Warranty and technical information is available from WALTCO's toll free customer service lines from 8:00 a.m. to 5:00 p.m. EST.

Waltco Lift Corp

285 Northeast Ave, Box 354, Tallmadge, OH 44278
1-800-211-3074, 330-633-9191


Please visit our websites: <http://www.waltco.com> or <http://www.hiab.com>

We're behind you all the way!

Chapter 2 Liftgate Terminology

TERMINOLOGY

- | | |
|----------------------------------|--------------------------------|
| 1. Travel Plate (Drop-In Design) | 9. Latch |
| 2. Rail (Track) | 10. Spec Tag |
| 3. Lift Cylinder | 11. Switch Assembly |
| 4. Crossbeam Box (Housing) | 12. Support Chain |
| 5. Lifting Chain | 13. Runner (Slider) |
| 6. Anchor Bolt | 14. Travel Ear and Grab Handle |
| 7. Pump Unit | 15. Platform |
| 8. Flow Control Valve | 16. Housing Cover |



CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION


Chapter 2 Liftgate Terminology

Explanation of Specification Tag

| Model Name | Description | Capacity |
|------------|------------------|-----------|
| MDL-10 | Medium Duty Lift | 1000 lbs. |

MODEL NAME

RATED CAPACITY
Based on an evenly
distributed load on the
platform flat surface.



SERIAL NUMBER
of liftgate. To be used
when ordering parts or
when contacting Waltco
for service or warranty
questions

**DATE OF
MANUFACTURE**
Month / Year

GR00241

Chapter 3 Operation Instructions


TO OPEN PLATFORM Drop-In Design Manual Close

Use switch to raise platform up out of travel plates.

Pull platform open to horizontal position.

**Never force platform open.
Keep hands away from pinch
points.**

Ref Operation Decal 80101577



GR02961


TO STORE PLATFORM Drop-In Design Manual Close

Use switch to raise platform all the way up.
Manually rotate platform up to vertical position.
Use switch to lower platform travel ears into
travel plates.

**Never force platform open.
Keep hands away from pinch
points.**

**If so equipped, turn power off to
liftgate to prevent unauthorized use.**

Ref Operation Decal 80101577



GR02961

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

OPERATION INSTRUCTIONS


LOADING OF PLATFORM

Load and unload from rear of platform and not side of platform. Never remove side linkage to load or unload platform.

Always load as close to center of platform and as close to truck sill as possible.

Never operate lift trucks on or over any part of platform.

This unit is intended for loading and unloaded of cargo only. Do not use for anything but its intended use.




GR02844

POWER OFF TO LIFTGATE (OPTIONAL SWITCH)

Turn power off to liftgate by turning off the Cab Shut-Off switch inside the cab of vehicle. This may be a toggle or rotary type switch.

Turn power off to liftgate to prevent unauthorized use of liftgate.



GR00379

PREVENTIVE MAINTENANCE

Waltco recommends that the MDL Series liftgate be inspected at 6 month or 3000 cycle intervals to help assure proper function and operation of the liftgate.

Note: Photocopy the following PM Checklist to help keep track of periodic maintenance on the liftgate. Keep completed form with maintenance records.

For more detailed instructions on the following checklist items, refer to the appropriate sections in this Owner's Manual.



Do not continue to use liftgate if any points of inspection, listed below, may cause you to think the liftgate is unsafe. Repair immediately.

If liftgate is found to be in need of repair or adjustment not covered in this manual, contact your nearest Waltco Distributor.

| WALTCO MDL SERIES LIFTGATE PREVENTIVE MAINTENANCE CHECKLIST | | | | |
|--|----|---------------------|-----------|--|
| PM Interval: 6 Months or 3000 Cycles | | Date: _____ | | Vehicle No. _____ |
| Mechanic: _____ | | Liftgate S/N: _____ | | Model: _____ |
| Check appropriate box below for each step: | | | | |
| 6 Month Liftgate PM Procedures | | | | |
| 1 | OK | Repair Required | Corrected | Check for apparent damage to the lifting structure, such as bent or distorted members or cracked welds, which may have resulted from overloading or abuse. |
| 2 | OK | Repair Required | Corrected | Check that all pins, bolts and fasteners are tight and secure. |
| 3 | OK | Repair Required | Corrected | Check for worn or damaged bearings sprockets, and roller chains. |
| 4 | OK | Repair Required | Corrected | Check that controls operate properly. |
| 7 | OK | Repair Required | Corrected | Check that cab shut-off switch cuts power to liftgate. |
| 5 | OK | Repair Required | Corrected | Check all battery cables and connections (both positive and ground cables) to be sure they are tight and free of corrosion. |
| 6 | OK | Repair Required | Corrected | Check that platform is level. |
| 7 | OK | Repair Required | Corrected | Check torsion bars and related hardware. |
| 8 | OK | Repair Required | Corrected | Check platform support chains. |
| 9 | OK | Repair Required | Corrected | Check for hydraulic leaks in hydraulic cylinder(s), hoses, fittings, and valves. |
| 10 | OK | Repair Required | Corrected | Check oil level in reservoir. |
| 11 | OK | Repair Required | Corrected | Check lowering speed of platform. |
| 12 | OK | Repair Required | Corrected | Check that all decals are in place and legible. |
| 13 | OK | Repair Required | Corrected | Lubricate the liftgate per the "Lubrication Instructions". |
| 12 Month Liftgate PM Procedures (Includes steps 1-13 above) | | | | |
| 14 | OK | Repair Required | Corrected | Inspect Pump Motor for wear and/or damage. |
| 15 | OK | Repair Required | Corrected | Drain and replace Hydraulic Fluid. |

PREVENTIVE MAINTENANCE

MONTHLY INSPECTION

Operate the lift-gate throughout its entire operational cycle. Check for:

- Damage to lifting structure such as bent or distorted members or cracked welds.
- Worn or damaged roller chain, sprockets, and bearings.
- Bent or distorted pins or damaged cylinder.
- Torsion bars are in place and properly working.
- All pivot and cylinder pins are securely in place, undamaged and retained by their proper fasteners.
- Damaged or worn bearings that pivot and cylinder pins rest in.
- Controls operate correctly (refer to chapter 3, "Operations Instructions")
- Check all power cables, ground cables, and connections.
- Clean and tighten all loose connections. Replace any damaged or corroded wires or connectors.



Do not continue to use lift-gate if any points of inspection listed at left, or below, may cause you to think the lift-gate is unsafe. Repair immediately.


If lift-gate is found to be in need of repair or adjustment not covered in this manual, contact your nearest Waltco Distributor.

PLATFORM ADJUSTMENT

Unfold and raise platform to bed level and check for:

1. If platform travels more than $\frac{1}{4}$ " above the top of the crossbeam box, and lift-gate is not an Above Floor model lift-gate, see below for adjustment.
2. If platform is uneven see below for adjustment.

Lower platform to ground. Remove access cover from crossbeam box.



If lift-gate is Above Floor model:

- Adjust as required to level platform.

If lift-gate is not an Above Floor model:

- Adjust platform so it is level with top of crossbeam box.




For non-Above Floor lift-gates, never adjust platform to travel above the crossbeam box.



Never adjust nut out less than $\frac{3}{8}$ " from end of anchor bolt.



Never have any part of your body underneath the platform while making adjustments.



ABOVE FLOOR TRAVEL

If above floor travel is to be reduced, additional links will need to be added to the lifting chains. If additional above floor travel is desired, contact Waltco for assistance. Ability to increase travel varies with each specific model of lift-gate and bed height of vehicle.

PREVENTIVE MAINTENANCE


HYDRAULICS

Inspect for oil leaks in:

- Hydraulic cylinder(s)
- Hydraulic hoses - Replace hoses if they show signs of excessive abrasion
- Hydraulic fittings and valves
- Tighten or replace all hydraulic components as may be required to stop oil leakage

CHECK AND FILL HYDRAULIC RESERVOIR

- Lower platform to ground and remove access cover.
- Remove reservoir breather cap.
- Oil level should be 1/2" from top of reservoir.
- If low, fill as required. Use appropriate fluid per chart.
- Replace breather cap.



GR02836

Recommended Fluids

| Temperature Range | Acceptable Fluids |
|-------------------|---|
| 0° to 120° F | Waltco Biodegradable Liftlube™ part #85803860 |
| | Shell Tellus S2 V 32 |
| | Chevron Rando HDZ 32 |
| -20° to 90° F | Waltco Biodegradable LiftLube Arctic part #85803866 |
| | Waltco All Season Hyd Oil Part 85803867 |
| | Shell Tellus S2 V 15 |
| | Mobil DTE 10 Excell 15 |

A good quality SAE 10W motor oil may also be used in temperatures above 32° F.

Fill reservoir

- Fill with recommended fluid or equivalent.
- Fill the reservoir to within 1/2" from the top.
- Fluids are available from the Waltco parts Dept. 1-800-411-5685 www.waltco.com

NOTE:

Do not use the following fluids:
Brake Fluid
Power steering fluid
Automatic Transmission Fluid (ATF)

Rev 06

PREVENTIVE MAINTENANCE


There is no speed adjustment on this liftgate.

Lowering speed is controlled by the pressure compensative valve plumbed at the cylinder. Regardless of weight on platform, liftgate should lower at approximately six (6) inches per second.

$$\frac{\text{Bed Height (inches)}}{6} = \text{Lowering Time (seconds)}$$



This liftgate must have the correct pressure compensative valve install:



GR00160

INSPECT DECALS AND LUBRICATE LIFTGATE

Inspect all decals per Chapter 5 of this manual. Replace any that are missing or damaged.


Lubricate liftgate per Chapter 6 of this manual.

ANNUAL INSPECTION

Inspect power motor:

- Disconnect battery cable.
- Remove end cover.
- Examine armature brushes for wear (Motor should be replaced if less than 1/8" long).
- Clean out all residue from inside of motor housing.
- Apply several drops of light weight machine oil to armature shaft bearing in motor end cover.
- Reassemble motor.

Drain hydraulic fluid and replace with new fluid per recommended fluids chart.




GR02836

PLACEMENT OF DECALS

| <div><div></div><div>All decals must be in place and legible or all warranties are void.</div></div> | | | | |
|---|--|-----|----------------------|---|
| ITEM | DECAL | QTY | PART NO | LOCATION |
| 1 | Safety Instructions | 1 | 80100850 | Locate in a conspicuous place near controls. |
| | Operation Decals (See Owners Manual for Details) | | | |
| | Snap Lock / Manual | 1 | 80101575 | |
| | Drop-In Manual | | 80101577 | |
| | Drop-In / Power Close | | 80101536 | |
| | Power Up Storage / Manual | | 80101639 | |
| | Power Up Storage / Power Close | | 80101578 | |
| | Drop-In with Cam / Manual | | 80101540 | |
| | Hazard Decal | 1 | 80101370 | |
| | Important Decal | 1 | 80101828 | |
| | 1250# Capacity Decal | 2 | 80100266 | Locate one in a conspicuous place near controls. |
| | 1600# Capacity Decal | | 80100252 | Locate one on curb side platform. |
| | 2000# Capacity Decal | | 80100253 | |
| | 3000# Capacity Decal | | 80100257 | |
| 2 | Caution Decal | 4 | 75089296 | Locate one in a conspicuous place near controls. Locate one in a conspicuous place on driver side of vehicle. |
| 3 | Protective Cover Decal | 2 | 75089282 | Locate one on hydraulic cylinder. Locate on back of crossbeam box. |
| 4 | Cab Shut Off Decal (optional) | 1 | 75089267 | Locate inside next to cab shut off switch. |
| 5 | Switch Decal | 1 | 80101532 80101533 | Locate on switch housing (single toggle switch) Locate on switch housing (2 toggle switch) |
| 6 | Warning Decal | 1 | 80100829 | Locate next to lift-gate circuit breaker. In applications where more than one circuit breaker is used, decal must be placed in both locations. |
| If your lift-gate is equipped with dual controls, an additional Safety Instruction decal (80100850) is to be placed in a conspicuous place near the second set of controls. <div></div> | | | | |
| | | | | |

PLACEMENT OF DECALS



CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

LUBRICATION INSTRUCTIONS


Lubricate lifting chains including sections in crossbeam box, rails, & runner assemblies with machine oil or motor oil.

Lubricate latch, inside rails, crossbeam box, and platform hinges with machine oil or motor oil.


Lubricate driver and passenger side tracks.

| Suggested Minimum Lubrication Schedule (days) | | | |
|---|-----------------|-------------|------------|
| Monthly Cycles | Light Duty | Medium Duty | Heavy Duty |
| <250 | 45 | 30 | 21 |
| 250-350 | 30 | 21 | 14 |
| 350-400 | 21 | 14 | 7 |
| >450 | Contact Factory | | |

* Lubricate every 30 days if cycles are unknown.



SCHEMATIC



CONFIDENTIAL NOT FOR DISTRIBUTION


CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION


HYDRAULIC PUMP UNIT

| ITEM | PART NUMBER | QTY | DESCRIPTION |
|------|-------------|-----|--|
| 1 | 43020013 | 3 | Sprocket, 13T, #50 Chain, MDL-12, 16, 20 |
| | 43120213 | 3 | Kit, 13T Sprocket, #50 Chain, MDL-12, 16, 20 |
| 3 | 75085184 | 2 | Locknut, 5/8-18 |
| 4 | 43020014 | 2 | Chain Anchor Bolt, 5/8"-18, #50 Chain |
| 5 | 80000419 | 2 | Kit, Roller Chain Master Link, #50 Chain |
| 6 | 90280726 | 1 | C/S Roller Chain, #50 |
| 7 | 43016019 | 1 | D/S Roller Chain, #50 |
| 8 | 91371201 | 1 | H-Frame Assembly |
| 9 | 91371225 | 1 | Access Door |
| 10 | 75086062 | 4 | Hex Bolt, ¼-20 x 3/4 |
| 11 | 75085164 | 4 | Tinnerman Clip, ¼" |
| 12 | 91371241 | 2 | Rail Cover |
| 13 | 7500012-1 | 4 | External Tooth Lock Washer, 1/4" |
| 14 | 75086874 | 4 | Screw, 1/4-20 X 5/8" Type F |




MAIN FRAME ASSEMBLY

| ITEM | PART NUMBER | QTY | DESCRIPTION |
|------|-------------|-----|--|
| 1 | 43020013 | 3 | Sprocket, 13T, #50 Chain, MDL-12, 16, 20 |
| | 43120213 | 3 | Kit, 13T Sprocket, #50 Chain, MDL-12, 16, 20 |
| 3 | 75085184 | 2 | Locknut, 5/8-18 |
| 4 | 43020014 | 2 | Chain Anchor Bolt, 5/8"-18, #50 Chain |
| 5 | 80000419 | 2 | Kit, Roller Chain Master Link, #50 Chain |
| 6 | 90280726 | 1 | C/S Roller Chain, #50 |
| 7 | 43016019 | 1 | D/S Roller Chain, #50 |
| 8 | 91371201 | 1 | H-Frame Assembly |
| 9 | 91371225 | 1 | Access Door |
| 10 | 75086062 | 4 | Hex Bolt, ¼-20 x 3/4 |
| 11 | 75085164 | 4 | Tinnerman Clip, ¼" |
| 12 | 91371241 | 2 | Rail Cover |
| 13 | 7500012-1 | 4 | External Tooth Lock Washer, 1/4" |
| 14 | 75086874 | 4 | Screw, 1/4-20 X 5/8" Type F |




RUNNER ASSEMBLY

| ITEM | PART NUMBER | QTY | DESCRIPTION |
|------|-------------|-----|---|
| | 91371350 | 1 | Runner Assembly, MDL-10, C/S |
| | 91371355 | 1 | Runner Assembly, MDL-10, D/S |
| 1 | 43016696 | 1 | Alum Ext Runner, Forked, 4x30.5 C/S |
| | 43116695 | 1 | Alum Ext Runner, Forked, 4x30.5 D/S |
| 2 | 91371240 | 1 | Runner Ear, Forked, Painted, SP |
| 3 | 75086218 | 4 | Hex Bolt, 3/8-16x1-1/4" LG GR 8 Plated |
| 4 | 4311668 | 1 | Stop, Platform, Forked Runner STD |
| 5 | 75085188 | 4 | Lock Nut, 3/8-16 Center-lock |
| 6 | 43016701 | 2 | Wear Pad Front Forked, 6" |
| 7 | 43016602 | 1 | Wear Pad Back Forked Runner |
| 8 | 75086709 | 8 | Screw, 10-32x3/8 FHSCS |
| 9 | 43020006 | 1 | Chain Anchor Block, MDL-12 |
| 10 | 80000419 | 1 | Roller Chain Master Link, #50 Chain, MDL-12 |
| 11 | 75085994 | 2 | Screw, 5/16-18x1 FHSCS Black Oxide |




PLATFORM ASSEMBLY

| ITEM | PART NUMBER | QTY | DESCRIPTION |
|------|-------------|-----|-----------------------------|
| | 91371110 | | ENTIRE PLATFORM ASSEMBLY |
| 1 | 27813982 | 1 | HINGE ROD |
| 2 | 27813983 | 4 | PIN, CRUSHED ENDS |
| 3 | 27813985 | 4 | HINGE BLOCK |
| 4 | 27813998 | 2 | ALUM EXTRUSION, 3WFR, RAMP |
| 5 | 75087494 | 16 | HEX SCREW, 3/8 x 2 |
| 6 | 91371111 | 2 | ALUM EXTRUSION, 3WFR, HINGE |
| 7 | 91371120 | 1 | SIDE PLATE ASSEMBLY, CS |
| 8 | 91371120 | 1 | SIDE PLATE ASSEMBLY, DS |
| 9 | 91371131 | 1 | ALUM EXTRUSION, STR, 2 x 6 |
| 10 | 91371131 | 5 | ALUM EXTRUSION, CTR, 2 x 6 |




DECK ASSEMBLY

| ITEM | PART NUMBER | QTY | DESCRIPTION |
|------|-------------|-----|---------------------------------------|
| 1 | 91371110 | 1 | DECK Assembly, 36 X 82, MOOD FLAP |
| 2 | 43120213 | 2 | SUPPORT CHAIN, 30" DP 28 LINKS |
| 3 | 43012382 | 2 | COVER, SUPPORT CHAIN, 30" DEEP |
| 4 | 75085178 | 4 | LOCKNUT, 7/16-14, STOVER GRADE |
| 5 | 75080125 | 2 | U-BOLT, #4, 7/16-14X2" |
| 6 | 91371129 | 1 | HINGE PIN, 1" MOOD FLAP, CS |
| 7 | 75089307 | 2 | GREASE ZERK, 5/16 DRIVE |
| 8 | 75089555 | 1 | SLOTTED SPRING PIN, 3/8" X 1 |
| 9 | 43020241 | 1 | TORSION BAR, .50 X 81 HT |
| 10 | 91371129 | 1 | HINGE PIN Assembly, 1", MOOD FLAP, DS |
| 11 | 75085188 | 5 | LOCK NUT, 3/8-16 CENTER LOCK |
| 12 | 7500010-22 | 2 | HEX BOLT, 3/8-16X2, GR 8 |
| 13 | 75086218 | 2 | HEX BOLT, 3/8-16X1-1/4"LG., GR 8 |
| 14 | 75085168 | 4 | HOG RING, SS 1" BLUNT 14 GA |
| 15 | 75089294 | 1 | HANDLE GRIP, 3/4 DIA RUBBER |
| 16 | 7500010-6 | 1 | HEX BOLT, 3/8-16X1"LG., GR 8 |



CYLINDER ASSEMBLY

| ITEM | PART NUMBER | QTY | DESCRIPTION |
|------|-------------|-----|---|
| 1 | 90995801 | 1 | Cylinder Assembly Complete, MDL-10 |
| A | 90995850 | 1 | Cylinder Assembly, MDL-10 |
| B | 43020013 | 1 | Sprocket, 13T, #50 Chain |
| | 80002232 | | Kit, 13T Sprocket with Pin & Hardware |
| C | 43020108 | 1 | Sprocket, 19T, #50 Chain |
| | 80002235 | | Kit 19T Sprocket with Pin & Hardware |
| D | 75088064 | 1 | Washer, 5/8" ID x 1-5/16" OD x .095" |
| E | 43016859 | 1 | Bearing, Shoe Assembly |
| F | 75086854 | 1 | 1/4 – 20x5/8" Type F Plated Round Head Phillips Screw |
| 2 | 75083039 | 1 | Adapter, 1/4" NPT Male x #4 JIC Male |
| 3 | 75085188 | 1 | Locknut, 3/8-16 |
| 4 | 75086218 | 1 | Hex Bolt, 3/8-16x1-1/4" |
| 5 | 43040082 | 1 | Tube, Flexible PVC, 3/16" ID x 60" LG |
| 6 | 7500026-5 | 1 | Elbow, 90 deg Barb, 1/8" NPT |
| 7 | 7010001-15 | 1 | Pressure Comp Valve, 2.5 GPM |
| 8 | 75083355 | 1 | Elbow, #6 Male SAE x 1/4 NPTM |



Repairs should be made only by authorized mechanics using WALTCO Replacement parts.

When ordering repair or replacement parts, please include all the information asked for below. If this information is not available, a complete written description or sketch of the required part will help WALTCO identify and deliver the needed part to you.

THE FOLLOWING INFORMATION MUST BE INCLUDED:

1. SERIAL NUMBER - [WALTCO lift-gate serial numbers can be found on the Specification Tag attached to the mount frame. (On older units the Specification Tag is located on the side or bottom of the platform.)]
2. MODEL NUMBER - [Or capacity]
3. PLATFORM SIZE

THEN INCLUDE THE FOLLOWING INFORMATION:

4. PART NUMBERS
5. DESCRIPTION
6. QUANTITY REQUIRED

MAIL, E-MAIL OR PHONE YOUR REQUEST TO:

Waltco Truck Equipment Co.
285 Northeast Avenue
Tallmadge, OH 44278
1-800-411-5685 FAX:
1-800-411-5684
E-MAIL: parts@waltco.com

ALL PARTS ARE F.O.B. FROM THE SHIPPING FACTORY

PLEASE NOTE:

To assure you of continuing and effective quality control, our warranty policy permits replacement of hydraulic cylinders, valves and motor pump units when their factory seals are intact. Parts under warranty will be exchanged promptly after careful inspection of the returned assemblies.

Every vehicle that has a WALTCO Lift gate must have legible WARNING AND OPERATION DECALS clearly posted on the vehicle and an OWNER'S MANUAL in the vehicle at all times as a guide for proper operation and maintenance.

Additional WARNING


DECALS, OPERATION DECALS and OWNER'S MANUALS
Can be obtained from WALTCO LIFT CORP.

NOTE: When ordering, give model
And serial number of the lift-gate.

BACK-UP CAMERA & MONITOR

MORGAN OLSON

BACKUP CAMERA SYSTEM



5" MONITOR & CAMERA KIT DRIVER / SERVICE MANUAL

BACK-UP CAMERA & MONITOR

TABLE OF CONTENTS

| | |
|---------------------------------------|----|
| 5" Color Backup Camera System..... | 61 |
| Components List and Description | 62 |
| Monitor Buttons..... | 63 |
| Menu Settings | 64 |
| Wiring Diagram | 65 |
| Camera Kit Installation | 66 |
| Monitor Kit Installation | 67 |
| System Technical Specifications . . . | 68 |

5" COLOR BACKUP CAMERA SYSTEM

Rosco Vision Systems introduces a revolutionary new backup camera system for commercial vehicles. The backup camera system utilizes a 5" inch monitor to display a 16:9 LCD screen when the vehicle shifts into reverse. This monitor allows the driver to see obstructions behind the vehicle for added convenience and safety.

The camera has an advanced CCD image sensor able to process excellent views under dark and light conditions. A 120° diagonal field of vision yields superb coverage behind the vehicle, and complies with the latest U.S. DOT guidelines when installed properly.

DISCLAIMER


- Please read this manual carefully before using the product.
- This system is intended as an aid for safe reverse operation.
- Drivers must always use extreme caution when operating a vehicle.
- Specifications subject to change without prior notice.
- Keep all cables AWAY from rotating and electrically noisy components.
- Make sure all cables are fastened properly so that you can prevent wire chafing, kinks, cuts, etc...
- Always consult your dealer when fitting any electrical or electronic equipment to a vehicle fitted with a CAN-bus or multiple system.

COMPONENT LIST AND DESCRIPTION


PART NO.

DESCRIPTION

STSM214



STSC141



REARVIEW
CAMERA

STSH214



4-PIN 26FT.
EXTENSION CABLE

WARNING

- To prevent electrical shock, DO NOT OPEN MONITOR CASE.
- Avoid exposing monitor to water, rain, moisture etc.
- Do not disassemble the camera. This voids the warranty.
- Disassembling the camera will compromise the waterproof seal.

5" Color Monitor Backup Camera System User Manual

MONITOR BUTTONS



NOTE: The monitor buttons do not function while the vehicle is in reverse. The vehicle must be running and in park/neutral/drive to use the buttons. It is recommended that the buttons are **ONLY** used in park/neutral.



POWER ON/OFF

Powers on the monitor and displays the Camera 1 channel by default.




LIGHT SENSOR (LEFT)

Used to adjust screen brightness automatically.

POWER LED (RIGHT)

Green when ON, Red when OFF



+/- VOLUME/MENU SETTING ADJUST BUTTONS


Adjusts the monitor sound volume by default.

Adjusts menu settings (e.g. brightness, contrast) according the menu setting selected



MENU SETTING AND PAGE TOGGLE

Brings up the monitor settings menu. Press the button again to scroll through the various settings and to access the camera settings menu page (see following page).



MENU SETTINGS SUMMARY

NOTE: The monitor buttons do not function while the vehicle is in reverse. The settings can only be adjusted when the vehicle is running in park/neutral/drive. It is recommended that the buttons are **ONLY** used in park/neutral.

MENU SETTINGS SCREEN 1:

"MONITOR DIM MODE SETTINGS / MONITOR BRIGHT MODE SETTINGS"

Press the menu button (see preceding page) to access this menu. Press the menu button again to scroll through the settings:


- **BRIGHTNESS** Press +/- to adjust the brightness.
- **CONTRAST** Press +/- to adjust the contrast
- **COLOR** Press +/- to adjust the color saturation
- **TINT** Press +/- to adjust the color tint/hue.
- **LANGUAGE** Press +/- to select the menu language.
- **RESET** Press either + or - to reset all menu settings to factory default.

MENU SETTINGS SCREEN 2:


"CAMERA SETTINGS"

Keep pressing the menu button to access page 2 of the settings:

- **CAM - HORIZONTAL** Press +/- to flip the Camera image horizontally.
- **CAM - VERTICAL** Press +/- to flip the Camera image vertically.
- **DIMMING** Press +/- to choose between "bright", "dim" and "auto". Choosing auto will allow the monitor to brighten and dim according to the amount of ambient light in the cabin.
- **SCALE** Press +/- to toggle the scale grid ON or OFF. If ON, the scale grid will appear when the driver shifts the vehicle into reverse in order to assist with distance perception.
- **ADJUST SCALE** Press + or - to begin adjusting the dimensions of the scale grid. Press - to switch between the vertical features of the scale and the horizontal "rungs". Press + to change the width, height, etc of the various features. Press MENU to save the settings and exit. See figure 1 for an example of the scale grid.

**fig 1**

BACK-UP CAMERA & MONITOR



CAMERA KIT INSTALLATION

CAMERA LOCATION

- Select a high and centered location at the rear of the vehicle to mount the STSC141 camera. See Figure 2 & 3.
- Mounting the camera near the lower area of the vehicle (e.g. the bumper) is not recommended. This reduces the view of the camera and increases the chance of physical damage to the camera.

INSTALL MOUNTING BRACKET

- Once the location for the camera is chosen, use a 3/16" drill bit to drill four holes into the vehicle using the mounting bracket as a guide. Be sure to clear any obstacles before drilling holes.
- Using a 3/4" drill bit, drill a cable hole into the vehicle using the large center hole in the mounting bracket as a guide, or choose a hole location as close as possible to the camera.

INSTALL CAMERA

- Install the camera mounting bracket. Mount the camera and sunshade onto the bracket. Insert the camera cable into the vehicle through the 3/4" hole and install the cable grommet on the hole.
- Connect the camera cable to the male-pinned connector of the camera extension cable (STSH214). Hand-tighten the coupling ring on the camera cable to ensure a secure connection, and slide the environmental boot over the connection.

ROUTE EXTENSION CABLE

- Route the extension cable to the vehicle cabin at the front of the vehicle. Adhere to a minimum bend radius of 2", and keep the cable away from hot, rotating, or electrically noisy components.
- Tuck the cable out of sight and secure/clamp the cable at as many spots as possible to prevent accidental snagging or damage to the cable.




fig 2

Mount camera assembly high and centered





fig 3

Obstructions behind truck



Typical monitor image of view from properly installed camera

Vehicle Rear Bumper

fig 4

MONITOR KIT INSTALLATION



MONITOR INSTALLATION

- Find a mounting location inside the vehicle cabin that is convenient to the driver (e.g. center of the dashboard, above the windshield on the ceiling, near the rear view mirror etc).
- Install U-Bracket as desired.
- Using the 4 supplied thumb screws, attach the monitor/sunshade assembly to the U-Bracket

FINALIZING THE INSTALLATION

- Connect the monitor 13-pin connector to the power harness 13-pin connector.
- Connect the camera extension cable from the rear-view camera to the 4-pin connector on the power harness. Slide the environmental sleeve of the extension over the connection.
- Tuck and fasten/clamp the power harness and extension cable as much as possible into the vehicle under the dashboard/pillar liners/etc to be out of sight from the driver and passengers. This reduces the possibility of the cables being hooked or snagged. Keep cables away from HOT, ROTATING and ELECTRICALLY NOISY components.
- Adhere to a 2-inch bend radius for all cables to prevent damage.
- Connect the 3- Pin connector to vehicle source.

CHECK THE REAR VIEW IMAGE

- Apply the parking brake and start the vehicle. Shift into reverse to ensure the monitor powers on and displays a rear image. Shift back into park/neutral and power off the vehicle.
- Adjust the angle camera as needed to achieve the desired rear view image. It is highly recommended that the image transmitted by the camera shows the rear bumper and area behind the vehicle. See Figure 4.

BACK-UP CAMERA & MONITOR

SYSTEM TECHNICAL SPECIFICATIONS:

STSM214 Monitor: (Includes STSM214/PHAR, STSA1004, STSU1004)

| | |
|--------------------------------|-------------------------------------|
| Screen size (diagonal): | 5" |
| Maximum No. of cameras: | 1 Input |
| Screen ratio: | 16:9 |
| Contrast ratio: | 500:1 |
| Video Input: | Composite, 1 V p-p +/- 20% @75 Ohms |
| Video system: | NTSC |
| Voltage input: | 12 ~32 Vdc |
| Operating temperature °F (C°): | 5°F to 149°F (-15°C to +65°C) |
| Storage temperature: | -4°F to +158°F (-20°C to + 70°C) |
| Shock rating: | 8g |
| Vibration Rating: | 6.9G @ 3mm amplitude & 10-30 Hz |
| Speaker Impedance: | 8 Ohms |
| Weight: | 0.66 lbs |
| Dimensions W x H x D: | 5.47" x 4.05" x 1.09" |

STSC141 Camera: (Includes Sunshade and Mounting Hardware)

| | |
|--------------------------------|-----------------------------------|
| Image device: | Sony ¼" CCD |
| Pixels: | 270,000 |
| TV lines: | 420 |
| InfraRed LED's: | 18 High-Output |
| Minimum illumination: | 0 Lux (infrared LED's on) |
| Night vision range: | 30 feet |
| Video Output: | 1.0 Vp-p, 75 Ohm |
| Shock rating: | 100g |
| Vibration rating: | 15g |
| Field of view: | 120° |
| Operating temperature °F (°C): | -4°F to +140°F (-20°C to + 60°C) |
| Storage temperature °F (°C): | -40°F to +176°F (-40°C to + 80°C) |
| Weight: | 0.6 lbs. |
| Dimensions W x H x D: | 3" x 2" x 2" |

STSH214 Extension Harness: (Included in Kit)

26' Heavy Duty w/ Twist - Lock Connectors

REAR VIEW MIRROR SYSTEM

MORGAN OLSON
REARVIEW MIRROR SYSTEM



6647RSSPH
6647LSSPH

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION


CONFIDENTIAL NOT FOR DISTRIBUTION

COMPONENTS LIST AND DESCRIPTIONS

Driver's Side Mirror Assembly

(1) Exterior left hand rear view mirror assembly
Including:


- (1) Heated flat head
- (1) Heated convex mirror head



Passenger's Side Mirror Assembly


(1) Exterior right hand rear view mirror assembly
Including:

- (1) Heated flat head
- (1) Heated convex mirror head



MIRROR SYSTEM ADJUSTMENT

Each rearview mirror head is 4-way hand adjustable (up/down/left/right).



According to FEDERAL MOTOR VEHICLE SAFETY STANDARDS No.111, rearview mirrors must be adjusted "...so as to provide the driver a view to the rear along both sides of the vehicle and shall be adjusted both in the horizontal and vertical directions to view the rearward scene."

Adjust the lookdown mirror head so as to provide the driver a view in front of the bumper and to the right of the front-right wheel.

OPERATING HEATED MIRRORS

Each rear view mirror head has a heating element behind the glass to assist with defogging / defrosting. When needed, simply depress the heater control switch. A small light (LED) on the bottom will confirm that heaters are on. Heaters will automatically turn off after 12 minutes.

MIRROR STORAGE


To collapse the mirror assemblies for vehicle storage, transport, or parking in areas where the width profile of the truck should be minimized, the driver should hold the vertical mirror arm between the mirror heads, and rotate it forward or rearward to preference.





CAUTION - be careful not to forcefully push the mirror assembly into the vehicle side or window so as to cause damage or bodily harm.

WEAR COMPONENT REPLACEMENT

During the life of the mirror assembly, the upper and lower locking mechanism components may wear out and need to be replaced. This is normal. See diagram below for details -- use wrenches compatible with 5/16" fasteners and apply tightening torque accordingly. Wear components are the same between LH and RH assemblies, except upper mounting bases.





HEATED MIRROR REPLACEMENT


Replace mirror heads when glass is broken, or when the heating element fails to heat the glass. The following steps apply to either a flat or convex mirror head.

Step 1: Pull out black grommet and cable from oval hole, and expose butt spliced connections. Cut wires as shown.


Step 2: Remove 5/16-18" hex head screw and lock washer to disassemble defective mirror head. Remove defective mirror head. Ensure that remaining mirror head harness stays in place.

Step 3: Loosely attach new mirror head to the clamp. Run heater harness through the oval into the tubular arm until the end reaches the other oval hole.

Step 4: Using provided butt splices, crimp black and white wires accordingly. Push wires inside the tubing towards the flattened end and re-attach oval grommet.



Step 5: Tighten mirror head hardware on the clamp to 200 in. lbs. be sure that clamp location on the tube is correct per below diagram:



**Morgan Olson Operator & Service Manual
for Keyless Entry Controller Diagnostics**
PN 46029040

**DELIVERY VEHICLE
★SOLUTIONS**



**MORGAN
★OLSON®**

1801 South Nottawa Road
Sturgis, MI 49091
(800) 233-4823

Operation Guide

Morgan Olson - 46029040


Cab Keyless Unlock

Curbside Door Unlock

Press and release the fob button.
The curbside and roadside doors unlock.
Auto relocks in 6-seconds.

Cab Manual Unlock

Press and release dash switch.
The curbside and roadside doors unlock.
Auto relocks in 6-seconds.



| LED | Operation | Status |
|-----------|------------------------------|---|
| Green LED | Flashes once every 5-seconds | System ON |
| | ON solid 6-seconds | Curbside and roadside doors unlocked (Cab Area) |
| Red LED | ON solid | Unlock request from unlock switch or fob |

Status LED on receiver located over driver door.

Keyfob Replacement & Code Management

Code Enrollment Option 1

1. Unplug 10-pin connector on the receiver, then reconnect it.
2. During the 1st 10-seconds after reconnecting the receiver, Press and hold the dash unlock switch for 5-seconds. Release the dash switch when you observe the red LED start to flicker flash. This means the receiver is in "learn" mode. The receiver will be in "learn" mode for 5-seconds.
3. When the receiver is in "learn" mode, press the button on the hand-held fob.
4. The red LED will double flash indicating the new fob has been enrolled.
5. Press the fob button once to test. If the green status LED turns on solid for 6-seconds, the fob has been enrolled successfully.

Code Enrollment Option 2

1. Open the receiver by removing the lid.
2. Identify the tact switch location on the PCB, small square component with a round button, which is near relays.
3. Press the tact switch once. The receiver will enter "learn" mode, indicatd by the red status LED flicker flashing. The receiver will remain in "learn" mode for 20-seconds.
4. Press the button on the new hand-held fob.
5. The red LED will double flash indicating the new fob has been enrolled.
6. Press the fob button once to test. If the green status LED turns on solid for 6-seconds, the fob has been enrolled successfully.

Code Removal OR Code Erase

1. Place receiver into "learn" mode as indicated above in Code Enrollment Option 2.
2. BUT instead of releasing the tact switch button, continue to press and hold it for a full 10-seconds.
3. When all codes are erased, the red status LED will double flash and exit "learn" mode automatically.
5. All codes will be erased.

Note:
Both code enrollment options
1 & 2 acheive the same results.

Trouble Shooting Guide

Morgan Olson - 46029040

Status & Diagnostic LEDs

Green LED

Power Reset

Both Red & Green LED ON for 10-seconds solid.

Quick Learn

Both Red & Green LEDs will turn OFF then Red LED will flicker flash for 5-seconds.
If a new fob is enrolled, it will double flash and turn OFF.

Power

Green status LED flashes once every 5-seconds.

Curbside and Roadside Doors

Green status LED turns on solid for 6-seconds.

Red LED

Input signals

When any input signal is detected (from fob or switch), the red LED will remain ON solid as long as the signal is present.

"Learn" Mode

Red LED flicker flashes in "learn" mode and double flashes when a new fob is enrolled or "learn" mode exits.

Error Code for continuous inputs signal from A1 dash switch or RF fob.


- A1 dash switch - single flash approximately once every 2- 3 seconds.
- RF fob enrolled - triple flash approximately once every 2 - 3 seconds.

| System Specifications | |
|--------------------------------------|--|
| P/N#46029040 / Model #P1550-R | |
| RANGE | 100 Feet Typical Up to 300 Feet |
| OUTPUT | 4 Relays, Positive, 5A |
| INPUT | 2 Inputs, +12V |
| FREQUENCY | 433 MHz |
| CODES | Rolling Codes Secure Encryption |
| VOLTAGE | 12VDC |
| CURRENT | 5 Amps Max per Output, (Relay) 10 Amp, Input (Max) |
| ANTENNA, OPTIONAL | Fixed, Standard (shown) Coin Style, Lithium, CR2032 |
| BATTERY | 100,000 1-second pulses 10 year shelf life |

Part Numbers

Transmitter - FOB
46029111

Receiver
46029040



| Trouble Shooting Guide | | Morgan Olson - 46029040 | |
|---|--|---|--|
| Sympton 1 No output from one or more outputs on receiver when transmitter buttons are pressed | | | |
| Possible Cause | | Corrective Actions | |
| 1.1 No signal from transmitter | | 1.1.1 Verify that transmitter is sending a signal and that transmitter is coded correctly. See Symptom 3. | |
| 1.2 One or more of the outputs have failed | | 1.2.1 Open receiver and observe yellow LEDs. The yellow output LED should turn ON as long as relay is ON. | |
| | | 1.2.2 Press each transmitter button in sequence. Using a volt meter, check each output. there should be a +12v present anytime the corresponding transmitter button is pressed. If no outputs, call factory for assistance. | |
| 1.3 Receiver outputs OK, but relays or equipment do not operate | | 1.3.1 Check wire and equipment for problem. | |
| 1.4 Fuse is blown | | 1.4.1 Check the F2 fuse in fuse block. If it is blown, replace it. | |
| 1.5 Wire harness problem | | 1.5.1 Check dash switch input wire connection on P1 green/yellow wire. If no voltage, correct wiring. | |
| Sympton 2 Receiver is Dead. Does not operate, no green power LED. | | | |
| Possible Cause | | Corrective Actions | |
| 2.1 Logic ground or power connection to receiver has failed | | 2.1.1 Check logic ground and logic power +12v. Use a voltmeter probe when checking voltage. | |
| | | 2.1.2 If either ground or power is not present, locate failure in wire harness | |
| 2.2 Chassis ground connection has failed | | 2.2.1 Check chassis ground connection. It should be clean and tight, no paint on metal, an external tooth star washer should be present, no rust or dirt in connections. | |
| | | 2.2.2 Chassis ground should be located on vehicle frame or directly to battery. | |
| 2.3 Receiver and / or microprocessor has failed | | 2.3.1 Check heart beat LED. If it is not flashing the microprocessor has failed. Call factory for assistance (in either case). | |
| | | 2.3.2 Check yellow output LEDs. If they DO NOT flash each time correspond- ing channel is activated, the receiver has failed. | |

| Trouble Shooting Guide | | Morgan Olson - 46029040 |
|---|--|-------------------------|
| Sympton 3 Poor range 0' to 25' (pulsating 0' to 25') | | |
| Possible Cause | Corrective Actions | |
| 3.1 Antenna damaged or grounded | 3.1.1 Check antenna placement. It should not be touching any metal or tinted glass. | |
| | 3.1.2 It should not be closer than 6' to any motors or relays / contactors. | |
| | 3.1.3 If antenna is cut or damaged, call factory for assistance. | |
| | Please Note: Antenna can NOT be shortened or altered in any way. | |
| 3.2 Poor ground connection | 3.2.1 Remove any paint or residue from metal. Using an external tooth star washer, tighten chassis ground ring terminal securely to vehicle frame. | |
| 3.3 Transmitter battery low | 3.3.1 Replace battery if voltage is 2.8 volts or below. All transmitters use: Lithium Coin Style - # CR2032 | |
| 3.4 Interference | 3.4.1 Electromagnetic interference (EMI) can be generated by motors, welding equipment, relays, RF from other radio frequency devices, etc. which may be in close proximity to the receiver or transmitter. | |
| | 3.4.2 Move closer to antenna or move vehicle out of range of EMI cause by high levels of RF from devices such as welding equipment, as this is a temporary problem. | |
| | 3.4.3 If EMI is cause by relays, door motors or lift motors then the receiver must be moved or shielded or the EMI noise diverted to ground. Call factory for detaiils / assistance. | |
| 3.5 Receiver component damaged or defective | 3.5.1 Call factory for assistance. | |
| 3.6 Other equipment installed in vehicle causing voltage drop when initially turning on | 3.6.1 Remove all other equipment from logic ground and power. Check range. If ok, move other antennas, route wires away from the receiver, move unit away from large motors or run logic power & ground directly from battery. | |

Limited Three (3) Year Warranty

Section One

Seller will warrant any product originally manufactured or assembled and sold by seller for a period of up to THREE YEARS.

Section Two

The following are in lieu of all warranties; expressed; implied; or statutory, including but not limited to, any implied warranty of merchantability of fitness for a particular purpose and of any other warranty obligation on the part of seller. Seller, except as otherwise hereinafter provided, warrants the goods against faulty workmanship or defective materials for a period of up to THREE YEARS.

Seller's sole and exclusive liability shall be (at seller's option) to repair; replace; or credit buyer for such goods which are returned by buyer during the applicable warranty period set forth above, provided that (I) seller is promptly notified in writing or by phone upon discovery by buyer that such goods failed to conform and an explanation of any alleged deficiencies, (II) such goods are returned to seller, (III) seller's examination of such goods shall disclose that such alleged deficiencies actually exist and were not caused by accident, misuse, neglect, alteration, improper installation, unauthorized repair or improper testing. If seller elects to repair or replace such goods, seller shall have a reasonable time to make such repairs or replace such goods.

Seller's warranties as herein above set forth shall not be enlarged, diminished, or affected by, and no obligation or liability shall arise or grow out of, seller's rendering of technical advice or service.

Damage to products caused by the customer or during installation cannot be claimed under this warranty. All devices returned that are not covered under the seller's warranty policy, will be charged a minimum of \$25.00 for evaluation plus additional charges for components and labor to repair the device not to exceed the original selling price. Seller considers the following to be typical examples of customer or installation damage: burned or broken traces on the printed circuit board, burned or damaged components, dirt or water residue on the printed circuit board or inside the case, modifications by the customer, broken cases or housings and dead batteries.

Section Three

A return material authorization number (RMA) must be issued by seller before any product is returned for evaluation or repair. Warranty repairs must be completed at authorized repair facilities.

© 2009 TouchTronics, Inc. All Rights Reserved. TouchTronics, the TouchTronics logo, and other TouchTronics marks are owned by TouchTronics and may be registered. TouchTronics assumes no responsibility for any errors that may appear in this manual. Information contained herein is subject to change without notice.

FCC Compliance and Advisory Statement. This hardware device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) reorient or relocate the receiving antenna; 2) increase the separation between the equipment and the receiver 3) connect the equipment to an outlet on a circuit different from that to which the receiver is connected; 4) consult the dealer or an experienced radio/TV technician for help. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulations.

Canadian DOC Statement. This digital device does not exceed the Class B limits for radio noise emissions from digital apparatus specified in the interference-causing equipment standard entitled "Digital Apparatus," ICES-003 of the Department of Communications.

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions: 1) this device may not cause interference, and 2) this device must accept any interference, including interference that may cause undesired operation of the device.

© 2009 TouchTronics, Inc. Tous droits réservés. TouchTronics, le logo TouchTronics et les autres marques TouchTronics sont la propriété exclusive de TouchTronics et sont susceptibles d'être des marques déposées. Toutes les autres marques sont la propriété exclusive de leurs détenteurs respectifs. TouchTronics décline toute responsabilité en cas d'erreurs dans ce manuel. Les informations énoncées dans le présent document peuvent faire l'objet de modifications sans avis préalable.

Déclaration FCC. Cet équipement a été testé et déclaré conforme à la section 15 du règlement de la FCC. Son fonctionnement est soumis aux conditions suivantes: 1) l'équipement concerné ne doit pas causer d'interférences dangereuses, et 2) il doit accepter toute interférence reçue, y compris les interférences risquant d'engendrer un fonctionnement indésirable. Cet équipement a été testé et déclaré conforme aux limitations prévues dans le cadre de la catégorie B des appareils numériques défini par la section 15 du règlement de la FCC. Ces limitations sont stipulées aux fins de garantir une protection raisonnable contre les interférences gênantes en installation résidentielle. Cet équipement génère, utilise et diffuse des ondes radio, et s'il n'est pas installé ni utilisé en conformité avec les instructions dont il fait l'objet, peut causer des interférences gênantes avec les communications radio. Cependant, nous ne pouvons vous garantir qu'une interférence ne se produira pas dans une installation particulière. Si cet équipement produit des interférences graves lors de réceptions radio ou télévisées qui peuvent être détectées en allumant et en éteignant l'équipement, vous êtes invités à les supprimer de plusieurs manières: 1) Réorienter ou déplacer l'antenne de réception; 2) Augmenter la distance séparant l'équipement et le récepteur 3) Connecter l'équipement à un circuit différent de celui auquel le récepteur est connecté; 4) Contacter votre revendeur ou un technicien radio/TV qualifié. Toutes modifications ou tous changements effectués sans l'accord exprès de la partie responsable de la conformité aux normes pourraient contraindre l'utilisateur à ne plus utiliser son équipement. Afin d'assurer la conformité avec les règlements FCC, les câbles d'interface blindés fournis avec le produit doivent être utilisés, ainsi que tout autres composants ou accessoires également spécifiés, lors de l'installation du produit.

Déclaration du Ministère des Communications Canadien. Cet appareil numérique est conforme aux limitations concernant l'émission d'interférences radio par des appareils numériques de catégorie B, telles que stipulées dans le cadre de la norme Appareils numériques ICES-003 édictée par le Ministère canadien de l'industrie.

Cet équipement a été déclaré conforme à la norme RSS-210 édictée par le Ministère canadien de l'industrie. Son fonctionnement est soumis aux conditions suivantes: 1) l'équipement concerné ne doit pas causer d'interférences, et 2) il doit accepter toute interférence reçue, y compris les interférences risquant d'engendrer un fonctionnement indésirable.



1801 South Nottawa Road
Sturgis, MI 49091
(800) 233-4823

VEHICLE JACKING POINTS




Front

Under the Frame just behind the Front Bumper.



Rear

Under the Frame just behind the Rear Bumper Shocks.



SCHEDULED MAINTENANCE

2016 calendar year 6.8L-2V/3V engines will change to SAE 5W-20 engine oil from SAE 5W-30 engine due to dynamometer certification requirements for 6.8L-3V engines.

FORD recommendation to the USPS is to follow OEM maintenance schedules outlined in the owner's manual. The USPS must follow the severe duty cycle as it pertains to engine oil changes at 5000 mile intervals or at 200 hours of operation. The severe duty schedule, found on page 274 of the 2016 E450 owner's manual. This document can be downloaded from Fleet.ford.com. The following pages from Ford's Scheduled Maintenance manual are included here for your convenience. (Pages 87-94)

Scheduled Maintenance

GENERAL MAINTENANCE INFORMATION

Why Maintain Your Vehicle?

Carefully following the maintenance schedule helps protect against major repair expenses resulting from neglect or inadequate maintenance and may help to increase the value of your vehicle when you sell or trade it. Keep all receipts for completed maintenance with your vehicle.

We have established regular maintenance intervals for your vehicle based upon rigorous testing. It is important that you have your vehicle serviced at the proper times. These intervals serve two purposes; one is to maintain the reliability of your vehicle and the second is to keep your cost of owning your vehicle down.

It is your responsibility to have all scheduled maintenance performed and to make sure that the materials used meet the specifications identified in this owner's manual. See **Capacities and Specifications** (page 191).

Failure to perform scheduled maintenance invalidates warranty coverage on parts affected by the lack of maintenance.

Why Maintain Your Vehicle at Your Dealership?

Factory-trained Technicians

Service technicians participate in extensive factory-sponsored certification training to help them become experts on the operation of your vehicle. Ask your dealership about the training and certification their technicians have received.

Genuine Ford and Motorcraft Replacement Parts

Dealerships stock Ford, Motorcraft and Ford-authorized branded re-manufactured replacement parts. These parts meet or exceed our specifications. Parts installed at your dealership carry a nationwide 24-month or unlimited mile (kilometer) parts and labor limited warranty.

If you do not use Ford authorized parts they may not meet our specifications and depending on the part, it could affect emissions compliance.

Convenience

Many dealerships have extended evening and Saturday hours to make your service visit more convenient and they offer one stop shopping. They can perform any services that are required on your vehicle, from general maintenance to collision repairs.

Note: *Not all dealers have extended hours or body shops. Please contact your dealer for details.*

Protecting Your Investment

Maintenance is an investment that pays dividends in the form of improved reliability, durability and resale value. To maintain the proper performance of your vehicle and its emission control systems, make sure you have scheduled maintenance performed at the designated intervals.

Your vehicle is very sophisticated and built with multiple, complex, performance systems. Every manufacturer develops these systems using different specifications and performance features. That is why it is important to rely upon your dealership to properly diagnose and repair your vehicle.

Scheduled Maintenance

Ford Motor Company has recommended maintenance intervals for various parts and component systems based upon engineering testing. Ford Motor Company relies upon this testing to determine the most appropriate mileage for replacement of oils and fluids to protect your vehicle at the lowest overall cost to you and recommends against maintenance schedules that deviate from the scheduled maintenance information.

We strongly recommend the use of only genuine Ford, Motorcraft or Ford-authorized re-manufactured replacement parts engineered for your vehicle.

Additives and Chemicals

This owner's manual and the Ford Workshop Manual list the recommended additives and chemicals for your vehicle. We do not recommend using chemicals or additives not approved by us as part of your vehicle's normal maintenance. Please consult your warranty information.

Oils, Fluids and Flushing

In many cases, fluid discoloration is a normal operating characteristic and, by itself, does not necessarily indicate a concern or that the fluid needs to be changed. However, a qualified expert, such as the factory-trained technicians at your dealership, should inspect discolored fluids that also show signs of overheating or foreign material contamination immediately.

Make sure to change your vehicle's oils and fluids at the specified intervals or in conjunction with a repair. Flushing is a viable way to change fluid for many vehicle sub-systems during scheduled maintenance. It is critical that systems are flushed only with new fluid that is the same as that required to fill and operate the system or using a Ford-approved flushing chemical.

Owner Checks and Services

Make sure you perform the following basic maintenance checks and inspections every month or at six-month intervals.

| Check every month |
|---|
| Engine oil level. |
| Function of all interior and exterior lights. |
| Tires (including spare) for wear and proper pressure. |
| Windshield washer fluid level. |

| Check every six months |
|---|
| Battery connections. Clean if necessary. |
| Body and door drain holes for obstructions. Clean if necessary. |
| Cooling system fluid level and coolant strength. |
| Door weatherstrips for wear. Lubricate if necessary. |

Scheduled Maintenance

| Check every six months |
|---|
| Hinges, latches and outside locks for proper operation. Lubricate if necessary. |
| Parking brake for proper operation. |
| Safety belts and seat latches for wear and function. |
| Safety warning lamps (brake, ABS, airbag and safety belt) for operation. |
| Washer spray and wiper operation. Clean or replace blades as necessary. |

Multi-point Inspection

In order to keep your vehicle running right, it is important to have the systems on your vehicle checked regularly. This can help identify potential issues and prevent major problems. We recommend having the following multi-point inspection performed at every scheduled maintenance interval to help make sure your vehicle keeps running great.

| Multi-point inspection | |
|--|--|
| Accessory drive belt(s) | Horn operation |
| Battery performance | Radiator, cooler, heater and A/C hoses |
| Engine air filter | Suspension component for leaks or damage |
| Exhaust system | Steering and linkage |
| Exterior lamps and hazard warning system operation | Tires (including spare) for wear and proper pressure** |
| Fluid levels*; fill if necessary | Windshield for cracks, chips or pits |
| For oil and fluid leaks | Washer spray and wiper operation |

* Brake, coolant recovery reservoir, automatic transmission, power steering and window washer.

**If your vehicle is equipped with a temporary mobility kit, check the tire sealant expiration Use By date on the canister. Replace as needed.

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

Scheduled Maintenance

Be sure to ask your dealership service advisor or technician about the multi-point vehicle inspection. It is a comprehensive way to perform a thorough inspection of your vehicle. Your checklist gives you immediate feedback on the overall condition of your vehicle.

NORMAL SCHEDULED MAINTENANCE

| Every 7500 miles (12000 km) or six months (whichever comes first) |
|--|
| Change engine oil and filter. |
| Rotate tires*, inspect tire wear and measure tread depth. |
| Inspect wheels and related components for abnormal noise, wear, looseness or drag. |
| Perform multi-point inspection (recommended). |

* Vehicles with dual rear wheels should rotate the front wheels when specified; rear wheels only if unusual wear is noted.

| Every 15000 miles (24000 km) or 12 months (whichever comes first) |
|---|
| Inspect automatic transmission fluid level. Consult dealer for requirements. |
| Inspect brake pads, rotors, hoses and parking brake. |
| Inspect engine cooling system strength and hoses. |
| Inspect exhaust system and heat shields. |
| Inspect steering linkage, ball joints, suspension, tie-rod ends, driveshaft and U-joints. |

| Other maintenance items | |
|--------------------------------|--|
| Every 30000 miles (48000 km) | Replace engine air filter. |
| Every 60000 miles (96000 km) | Change automatic transmission fluid and filter (5-Speed Transmission only). Consult dealer for requirements. |
| | Replace front wheel bearing grease and grease seal if non-sealed bearings are used. |
| Every 97500 miles (156000 km) | Replace spark plugs. |
| Every 105000 miles (168000 km) | Change engine coolant.* |

Scheduled Maintenance

| Other maintenance items | |
|--------------------------------|---|
| | Replace rear axle fluid. |
| | Inspect accessory drive belt(s).** |
| Every 150000 miles (240000 km) | Change automatic transmission fluid. |
| | Change automatic transmission filter.*** |
| | Replace accessory drive belt(s) if not replaced within the last 100000 miles (160000 km). |
| | Replace front wheel bearings and seals if non-sealed bearings are used. |
| Every two years | Replace brake fluid. |

* Initial replacement at six years or 105000 miles (168000 kilometers), then every three years or 45000 miles (72000 kilometers).

** If not replaced, inspect every 15000 miles (24000 kilometers).

*** Rear-wheel drive vehicles only.

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

Scheduled Maintenance

SPECIAL OPERATING
CONDITIONS SCHEDULED
MAINTENANCE

If you operate your vehicle **primarily** in any of the following conditions, you need to

perform extra maintenance as indicated. If you operate your vehicle **occasionally** under any of these conditions, it is not necessary to perform the extra maintenance. For specific recommendations, see your dealership service advisor or technician.

| Towing a trailer or using a car-top carrier | |
|---|--|
| Inspect frequently, service as required | Inspect U-joints. |
| | See axle maintenance items under Exceptions . |
| Every 5000 miles (8000 km) | Inspect the wheels and related components for abnormal noise, wear, looseness or drag. |
| | Rotate tires*, inspect tires for wear and measure tread depth. |
| Every 5000 miles (8000 km) or six months | Change engine oil and filter. |
| | Inspect U-joints. |
| Every 30000 miles (48000 km) | Replace front wheel bearing grease and grease seals if non-sealed bearings are used. |
| Every 60000 miles (96000 km) | Replace spark plugs. |

*Vehicles equipped with dual rear wheels should rotate the front wheels when specified; rear wheels only if unusual wear is noted.

| Extensive idling or low-speed driving for long distances, as in heavy commercial use (such as delivery, taxi, patrol car or livery) | |
|---|--|
| Every 5000 miles (8000 km) | Inspect brake system. |
| | Inspect wheels and related components for abnormal noise, wear, looseness or drag. |
| | Rotate tires*, inspect tires for wear and measure tread depth. |
| Every 5000 miles (8000 km) or six months | Inspect U-joints. |

Scheduled Maintenance

| Extensive idling or low-speed driving for long distances, as in heavy commercial use (such as delivery, taxi, patrol car or livery) | |
|---|--|
| Every 5000 miles (8000 km) or six months or 200 engine hours | Change engine oil and filter. |
| Every 30000 miles (48000 km) | Replace front wheel bearing grease and grease seals if non-sealed bearings are used. |
| Every 60000 miles (96000 km) | Replace spark plugs. |

*Vehicles equipped with dual rear wheels should rotate the front wheels when specified; rear wheels only if unusual wear is noted.

| Operating in dusty or sandy conditions (such as unpaved or dusty roads) | |
|---|--|
| Inspect frequently, service as required | Replace engine air filter. |
| Every 5000 miles (8000 km) | Inspect the wheels and related components for abnormal noise, wear, looseness or drag. |
| | Rotate tires*, inspect tires for wear and measure tread depth. |
| Every 5000 miles (8000 km) or six months | Change engine oil and filter. |
| | Inspect U-joints. |
| Every 30000 miles (48000 km) | Replace front wheel bearing grease and grease seals if non-sealed bearings are used. |
| Every 50000 miles (80000 km) | Change rear axle fluid. |

*Vehicles equipped with dual rear wheels should rotate the front wheels when specified; rear wheels only if unusual wear is noted.

Exceptions

There are several exceptions to the Normal Schedule:

Normal vehicle axle maintenance: Rear axles and power take-off units with synthetic fluid and light-duty trucks equipped with Ford-design axles are lubricated for life; do not check or change fluid unless a leak is suspected, service is required or the assembly has been submerged in water. During long periods of trailer towing with outside temperatures

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

CONFIDENTIAL NOT FOR DISTRIBUTION

Scheduled Maintenance

above 70°F (21°C) and at wide-open throttle for long periods above 45 mph (72 km/h), change non-synthetic rear axle fluid every 3000 miles (4800 kilometers) or three months, whichever comes first. This interval can be waived if the axle is filled with 75W140 synthetic gear fluid meeting Ford specification WSL-M2C192-A, part number FITZ-19580-B, or equivalent. Add friction modifier XL-3 (EST-M2C118-A) or equivalent for complete refill of Traction-Lok rear axles. See **Capacities and Specifications** (page 191).

California fuel filter replacement: If you register your vehicle in California, the California Air Resources Board has determined that the failure to perform this maintenance item does not nullify the emission warranty or limit recall liability before the completion of your vehicle's useful life. Ford Motor Company, however, urges you to have all recommended maintenance services performed at the specified intervals and to record all vehicle service.

Hot climate oil change intervals: Vehicles operating in the Middle East, North Africa, Sub-Saharan Africa or locations with similar climates using an American Petroleum Institute (API) Certified for Gasoline Engines (Certification mark) oil of SM or SN quality, the normal oil change interval is 5000 miles (8000 kilometers).

If the available API SM or SN oils are not available, then the oil change interval is 3000 miles (4800 kilometers).

Engine air filter replacement: The life of the engine air filter is dependent on exposure to dusty and dirty conditions. Vehicles operated in these conditions require frequent inspection and replacement.

SCHEDULED MAINTENANCE RECORD

Repair Order #:

Distance:

Engine hours (optional):

Multi-point inspection (recommended):


Signature:

Dealer stamp

FORD Recommended Maintenance Schedule For Extreme Duty Extensive idling and/or driving at low speeds

| Mileage | 5K | 10K | 15K | 20K | 25K | 30K | 35K | 40K | 45K | 50K | 55K | 60K | 65K | 70K | 75K | 80K | 85K | 90K | 95K | 100K | 105K | 110K | 115K | 120K | 125K | 130K | 135K | 140K | 145K | 150K |
|---|----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|------|------|------|------|------|------|------|------|------|------|------|
| MEMO: Gas engine; Up to 6.0 quarts of oil | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X | X |
| Replace platinum-tipped spark plugs | | | | | | | | | | | | X | | | | | | | | | | | | X | | | | | | |
| Inspect complete exhaust system and heat shields | | | X | | | | | | X | | | | | | X | | | | | | X | | | | | X | | | | |
| Replace front 4x2 wheel bearings and grease seals, lubricate and adjust bearings | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | X |
| Replace accessory drive belts (if not replaced within last 100,000 miles) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | X |
| Change Premium Gold engine coolant | | | | | | | | | | | | | | | | | | | | | X | | | | | | | | | X |
| Replace rear axle lubricant | | | | | | | | | | | | | | | | | | | | | X | | | | | | | | | |
| Inspect and lubricate all non-sealed steering linkage, ball joints, suspension joints, half and drive-shafts and u-joints | X | X | X | X | X | X | X | X | X | X | X | | X | X | X | X | X | | X | X | X | X | X | | X | X | X | X | X | |
| Inspect 4x2 front wheel bearings; replace grease and grease seals, and adjust bearings | | | | | | X | | | | | | X | | | | | | X | | | | | | X | | | | | | X |
| Change rear axle fluid (vehicles equipped with Dana axles) | | | | | | | | | | | | | | | | | | | | X | | | | | | | | | | |
| Change automatic transmission fluid and filter | | | | | | | | | | | | X | | | | | | | | | | | | X | | | | | | |
| Inspect brake pads/shoes/rotors/drums, brake lines and hoses, and parking brake system | X | X | X | X | X | | X | X | X | X | X | | X | X | X | X | X | | X | X | X | X | X | | X | X | X | X | X | |
| Inspect cooling system and hoses | | | X | | | | | | X | | | | | | X | | | | | | X | | | | | | X | | | |
| Inspect accessory drive belt(s) | | | | | | | | | | | | | | | | | | | | | X | | | X | | | | | | |




[illegible]

8. VENDOR MAY REPLACE TIGTAILS WITH WIRING TO APPROVED MOLDS OR CONNECTIONS. TIGTAILS SHOWN IN TERMINAL VIEW.
7. HARNESS TO BE TESTED FOR CONTENT, OPENS, SHORTS, AND CONTINUITY.
6. CONNECTORS SHOWN FROM WIRE ENTRY SIDE, UNLESS OTHERWISE NOTED.
5. SPLICES TO BE AUTOMATED WITH SOLDER, AND ADHESIVE LINED HEAT SHRINK TUBING.
4. BREAK 111106; 6" AT INTERVALS, 2" AT 18" INTERVALS, FOR UNINTERRUPTED LOOM LENGTHS GREATER THAN 24", AND 2" AT LOOM ENDS.
3. HARNESS TO HAVE A LABEL SHOWING MORGAN OLSON PART NUMBER, POSITION LEVEL, AND DATE OF MANUFACTURE.
2. SEW IT-HI TEMP POLY LOOM UNLESS OTHERWISE NOTED.
1. SIX WIRE.

PROPRIETARY



This drawing and the information and data contained herein constitute valuable proprietary trade secret information of Morgan Disson. It is not to be copied, duplicated or further disclosed or disseminated for any purpose other than that purpose for which it was originally provided, without the prior written consent of Morgan Disson.







| HARNESSES AND LOOM TOLERANCES | |
|-------------------------------|----------|
| UP TO 60" | = -0/+2" |
| 60" TO 100" | = -0/+3" |
| 100" TO 200" | = -0/+5" |
| 200" TO 400" | = -0/+8" |
| 400" TO 600" | = -0/+7" |
| OVER 600" | = -0/+8" |
| BO TO BO | = -0/+2" |



LENGTHS APPLY FROM BREAKOUT TO BREAKOUT OR BREAKOUT TO WIRE ENTRY, SIDE OF CONNECTOR, OR END OF COVER

| | | | |
|------------------------------|---------------|-----------|-----------------|
| HARN BAT POS 2GA BREAKER 24" | DRAWING NO. | | SCALE |
| | SHT 1 OF 1 | 132088206 | NONE REV DEI |











| | | |
|-------------|------------------------|---------|
| DRAWING NO. | REV | SHT |
| 155084201 | | 1 of 1 |
| REV. | DESCRIPTION | BY DATE |
| | RELEASE FOR PRODUCTION | |
| | | |
| | | |
| | | |
| | | |



| CIRCUIT | DESCRIPTION | END POINTS | FUNCTION |
|---------|---------------|-------------------|-------------------------|
| 000 | 10/12/16 WHI | A1,A2,H1,J1,K1,P1 | GROUND |
| 001A | 16 V10 | N,N1 | CLER/MKR/ICC LAMPS |
| 001B | 14/16 BRN | A1,A2,N | CLER/MKR/ICC LAMPS |
| 002 | 14 GRN | A2,P1 | RH TURN/COMBO |
| 003 | 14 YEL | A2,O1 | LH TURN/COMBO |
| 004 | 14/16 PNK | A1,A2,F1 | BACKUP SIGNAL |
| 005A | 16 V10/WHI | N,N1 | STOP ONLY |
| 005B | 14 RED | A2,N | LOAD DOME LAMP(S) |
| 007 | 14 ORN | A2,H2 | DASH ILLUMINATION |
| 008A | 16 V10/GRY | M,M1 | DOME BATTERY FEED |
| 008B | 16 BLU | H1,K1,M | RH ISO TURN |
| 009 | 12/16 RED | D1,F2,H1 | LH ISO TURN |
| 042A | 16 GRN/ORN | N,N1 | RH TURN COMBO |
| 042B | 16 GRN/BLK | N,N1 | LH TURN COMBO |
| 043A | 16 GRY/ORN | N,N1 | LOAD DM 3W SW |
| 043B | 16 YEL/BLK | N,O1 | LOAD DM 3W SW |
| 052A | 16 GRY/BRN | N,N1 | HVAC GROUND |
| 052B | 14 GRN | N,N1 | ELEX HVAC POWER |
| 053A | 16 GRY/BRN | N,N1 | WIPER POWER (ACCY) |
| 053B | 16 BLU/WHI | N,O1 | WIPER PARK SWITCH B+ |
| 090 | 16 BLU/YEL | A2,H1 | WIPER LOW |
| 091 | 16 WHI/ORN | H2,P2 | WIPER HIGH |
| 100 | 12 WHI/ORN | E1,H1 | WIPER MOTOR SWITCH |
| 101 | 12 ORN | F1,J1,SPLICE | WASHER PUMP |
| 103 | 14 YEL | A1,SPLICE | AC DEMAND |
| 106 | 16 BL | A1,J1 | AC DEMAND |
| 107 | 16 GRN/WHI | A1,J1 | LIGHTER/12V OUTLET |
| 108 | 16 RED/WHI | A1,J1 | LOAD DOME RELAY COIL B+ |
| 109 | 16 ORN | A1,J1 | HVAC BLOWER RELAY COIL |
| 111 | 16 PNK/BLK | F1,J1 | LIGHTER/12V OUTLET GND |
| 114A | 16 GRY/YEL | M,M1 | BATTERY FEED #1 |
| 114B | 16 PPL | M,P3 | BATTERY FEED #1 |
| 116 | 14 RED/GRN | E1,H1 | AUX BATTERY POWER |
| 118 | 16 GRY | G1,H1 | AUX ACCESSORY POWER |
| 119 | 16 V10/GRY | M1,M1 | SPARE BATTERY FEED |
| 200 | 14 WHI/BLK | H2,P2 | SPARE BATTERY FEED |
| 202A | 12 WHI/RED | N,N1 | BATTERY FEED #2 |
| 202B | 10 YEL | E1,N | ACCESSORY FEED #2 |
| 204 | 14 RED/BLK | B2,D1,H1 | HVAC POWER FEED (ACCY) |
| 206 | 12 ORN/BLK | B2,D1,H1 | SWITCHED BATTERY LOADS |
| 207A | 14 BRN/RED | M,M1 | AUXILIARY LOADS GND |
| 207B | 12 RED/YEL | E1,M | DASH FAN LOW |
| 211 | 10 RED/BLK | D1,F1 | DASH FAN HIGH |
| 214 | 10 ORN/BLK | E1,F1 | CAB DOME LAMP |
| 215 | 12 ORN/BLK | A1,A2,H2 | RH SPEAKER (-) |
| 224 | 14 RED/GRN | A1,A2,H2 | RH SPEAKER (+) |
| 226 | 14 ORN/GRN | A1,A2,H2 | LH SPEAKER (-) |
| 300 | 10/12 WHI/RED | A1,B2,H1,P1 | LH SPEAKER (+) |
| 304 | 16 YEL/BLK | A1,H2 | RADIO BATTERY POWER |
| 305 | 16 GRN/BLK | A1,H2 | RDO/FAN/CAM ACCY POWER |
| 306 | 16 TAN | A2,H2 | SPARE GROUND |
| 400 | 16 GRY/BLK | B1,H2 | SPARE BATTERY POWER |
| 401 | 16 GRY/WHI | B1,H2 | LH TURN JUMPER |
| 402 | 16 WHI/BLK | B1,H2 | RH TURN JUMPER |
| 403 | 16 WHI/GRN | B1,H2 | |
| 404 | 14 YEL/RED | E1,H1 | |
| 405 | 16 ORN/BLK | A1,D1,H1 | |
| 416 | 16 GRY | M1,M1 | |
| 900 | 12 WHI/BLU | C1,P2 | |
| 904 | 12 RED/WHI | C1,E1 | |
| JPR1 | 14 PNK | O2,O2 | |
| JPR2 | 14 BLK | R2,R2 | |


*SEE NOTES

OPTIONAL: CIRCUITS 400 & 401 MAY BE SUPPLIED AS STANDARD SPEAKER "ZIP CORO" PAIRS. CIRCUIT NUMBER AND CONNECTOR INDEXING MUST BE MAINTAINED AS SHOWN.

OPTIONAL: CIRCUITS 402 & 403 MAY BE SUPPLIED AS STANDARD SPEAKER "ZIP CORO" PAIRS. CIRCUIT NUMBER AND CONNECTOR INDEXING MUST BE MAINTAINED AS SHOWN.

| | | |
|--|--|--|
| PROPRIETARY | | |
| This drawing and the information and data contained herein are the property of Morgan Olson and may not be copied, reproduced, or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system, without the prior written consent of Morgan Olson. | | |
| MORGAN OLSON | | |
| GENERAL STANDARDS UNLESS OTHERWISE NOTED | | |
| 1. TOLERANCES: FRACTIONS: .0005, .001, .002, .003, .004, .005, .006, .007, .008, .009, .010, .015, .020, .025, .030, .035, .040, .045, .050, .055, .060, .065, .070, .075, .080, .085, .090, .095, .100, .105, .110, .115, .120, .125, .130, .135, .140, .145, .150, .155, .160, .165, .170, .175, .180, .185, .190, .195, .200, .205, .210, .215, .220, .225, .230, .235, .240, .245, .250, .255, .260, .265, .270, .275, .280, .285, .290, .295, .300, .305, .310, .315, .320, .325, .330, .335, .340, .345, .350, .355, .360, .365, .370, .375, .380, .385, .390, .395, .400, .405, .410, .415, .420, .425, .430, .435, .440, .445, .450, .455, .460, .465, .470, .475, .480, .485, .490, .495, .500, .505, .510, .515, .520, .525, .530, .535, .540, .545, .550, .555, .560, .565, .570, .575, .580, .585, .590, .595, .600, .605, .610, .615, .620, .625, .630, .635, .640, .645, .650, .655, .660, .665, .670, .675, .680, .685, .690, .695, .700, .705, .710, .715, .720, .725, .730, .735, .740, .745, .750, .755, .760, .765, .770, .775, .780, .785, .790, .795, .800, .805, .810, .815, .820, .825, .830, .835, .840, .845, .850, .855, .860, .865, .870, .875, .880, .885, .890, .895, .900, .905, .910, .915, .920, .925, .930, .935, .940, .945, .950, .955, .960, .965, .970, .975, .980, .985, .990, .995, 1.000, 1.005, 1.010, 1.015, 1.020, 1.025, 1.030, 1.035, 1.040, 1.045, 1.050, 1.055, 1.060, 1.065, 1.070, 1.075, 1.080, 1.085, 1.090, 1.095, 1.100, 1.105, 1.110, 1.115, 1.120, 1.125, 1.130, 1.135, 1.140, 1.145, 1.150, 1.155, 1.160, 1.165, 1.170, 1.175, 1.180, 1.185, 1.190, 1.195, 1.200, 1.205, 1.210, 1.215, 1.220, 1.225, 1.230, 1.235, 1.240, 1.245, 1.250, 1.255, 1.260, 1.265, 1.270, 1.275, 1.280, 1.285, 1.290, 1.295, 1.300, 1.305, 1.310, 1.315, 1.320, 1.325, 1.330, 1.335, 1.340, 1.345, 1.350, 1.355, 1.360, 1.365, 1.370, 1.375, 1.380, 1.385, 1.390, 1.395, 1.400, 1.405, 1.410, 1.415, 1.420, 1.425, 1.430, 1.435, 1.440, 1.445, 1.450, 1.455, 1.460, 1.465, 1.470, 1.475, 1.480, 1.485, 1.490, 1.495, 1.500, 1.505, 1.510, 1.515, 1.520, 1.525, 1.530, 1.535, 1.540, 1.545, 1.550, 1.555, 1.560, 1.565, 1.570, 1.575, 1.580, 1.585, 1.590, 1.595, 1.600, 1.605, 1.610, 1.615, 1.620, 1.625, 1.630, 1.635, 1.640, 1.645, 1.650, 1.655, 1.660, 1.665, 1.670, 1.675, 1.680, 1.685, 1.690, 1.695, 1.700, 1.705, 1.710, 1.715, 1.720, 1.725, 1.730, 1.735, 1.740, 1.745, 1.750, 1.755, 1.760, 1.765, 1.770, 1.775, 1.780, 1.785, 1.790, 1.795, 1.800, 1.805, 1.810, 1.815, 1.820, 1.825, 1.830, 1.835, 1.840, 1.845, 1.850, 1.855, 1.860, 1.865, 1.870, 1.875, 1.880, 1.885, 1.890, 1.895, 1.900, 1.905, 1.910, 1.915, 1.920, 1.925, 1.930, 1.935, 1.940, 1.945, 1.950, 1.955, 1.960, 1.965, 1.970, 1.975, 1.980, 1.985, 1.990, 1.995, 2.000, 2.005, 2.010, 2.015, 2.020, 2.025, 2.030, 2.035, 2.040, 2.045, 2.050, 2.055, 2.060, 2.065, 2.070, 2.075, 2.080, 2.085, 2.090, 2.095, 2.100, 2.105, 2.110, 2.115, 2.120, 2.125, 2.130, 2.135, 2.140, 2.145, 2.150, 2.155, 2.160, 2.165, 2.170, 2.175, 2.180, 2.185, 2.190, 2.195, 2.200, 2.205, 2.210, 2.215, 2.220, 2.225, 2.230, 2.235, 2.240, 2.245, 2.250, 2.255, 2.260, 2.265, 2.270, 2.275, 2.280, 2.285, 2.290, 2.295, 2.300, 2.305, 2.310, 2.315, 2.320, 2.325, 2.330, 2.335, 2.340, 2.345, 2.350, 2.355, 2.360, 2.365, 2.370, 2.375, 2.380, 2.385, 2.390, 2.395, 2.400, 2.405, 2.410, 2.415, 2.420, 2.425, 2.430, 2.435, 2.440, 2.445, 2.450, 2.455, 2.460, 2.465, 2.470, 2.475, 2.480, 2.485, 2.490, 2.495, 2.500, 2.505, 2.510, 2.515, 2.520, 2.525, 2.530, 2.535, 2.540, 2.545, 2.550, 2.555, 2.560, 2.565, 2.570, 2.575, 2.580, 2.585, 2.590, 2.595, 2.600, 2.605, 2.610, 2.615, 2.620, 2.625, 2.630, 2.635, 2.640, 2.645, 2.650, 2.655, 2.660, 2.665, 2.670, 2.675, 2.680, 2.685, 2.690, 2.695, 2.700, 2.705, 2.710, 2.715, 2.720, 2.725, 2.730, 2.735, 2.740, 2.745, 2.750, 2.755, 2.760, 2.765, 2.770, 2.775, 2.780, 2.785, 2.790, 2.795, 2.800, 2.805, 2.810, 2.815, 2.820, 2.825, 2.830, 2.835, 2.840, 2.845, 2.850, 2.855, 2.860, 2.865, 2.870, 2.875, 2.880, 2.885, 2.890, 2.895, 2.900, 2.905, 2.910, 2.915, 2.920, 2.925, 2.930, 2.935, 2.940, 2.945, 2.950, 2.955, 2.960, 2.965, 2.970, 2.975, 2.980, 2.985, 2.990, 2.995, 3.000, 3.005, 3.010, 3.015, 3.020, 3.025, 3.030, 3.035, 3.040, 3.045, 3.050, 3.055, 3.060, 3.065, 3.070, 3.075, 3.080, 3.085, 3.090, 3.095, 3.100, 3.105, 3.110, 3.115, 3.120, 3.125, 3.130, 3.135, 3.140, 3.145, 3.150, 3.155, 3.160, 3.165, 3.170, 3.175, 3.180, 3.185, 3.190, 3.195, 3.200, 3.205, 3.210, 3.215, 3.220, 3.225, 3.230, 3.235, 3.240, 3.245, 3.250, 3.255, 3.260, 3.265, 3.270, 3.275, 3.280, 3.285, 3.290, 3.295, 3.300, 3.305, 3.310, 3.315, 3.320, 3.325, 3.330, 3.335, 3.340, 3.345, 3.350, 3.355, 3.360, 3.365, 3.370, 3.375, 3.380, 3.385, 3.390, 3.395, 3.400, 3.405, 3.410, 3.415, 3.420, 3.425, 3.430, 3.435, 3.440, 3.445, 3.450, 3.455, 3.460, 3.465, 3.470, 3.475, 3.480, 3.485, 3.490, 3.495, 3.500, 3.505, 3.510, 3.515, 3.520, 3.525, 3.530, 3.535, 3.540, 3.545, 3.550, 3.555, 3.560, 3.565, 3.570, 3.575, 3.580, 3.585, 3.590, 3.595, 3.600, 3.605, 3.610, 3.615, 3.620, 3.625, 3.630, 3.635, 3.640, 3.645, 3.650, 3.655, 3.660, 3.665, 3.670, 3.675, 3.680, 3.685, 3.690, 3.695, 3.700, 3.705, 3.710, 3.715, 3.720, 3.725, 3.730, 3.735, 3.740, 3.745, 3.750, 3.755, 3.760, 3.765, 3.770, 3.775, 3.780, 3.785, 3.790, 3.795, 3.800, 3.805, 3.810, 3.815, 3.820, 3.825, 3.830, 3.835, 3.840, 3.845, 3.850, 3.855, 3.860, 3.865, 3.870, 3.875, 3.880, 3.885, 3.890, 3.895, 3.900, 3.905, 3.910, 3.915, 3.920, 3.925, 3.930, 3.935, 3.940, 3.945, 3.950, 3.955, 3.960, 3.965, 3.970, 3.975, 3.980, 3.985, 3.990, 3.995, 4.000, 4.005, 4.010, 4.015, 4.020, 4.025, 4.030, 4.035, 4.040, 4.045, 4.050, 4.055, 4.060, 4.065, 4.070, 4.075, 4.080, 4.085, 4.090, 4.095, 4.100, 4.105, 4.110, 4.115, 4.120, 4.125, 4.130, 4.135, 4.140, 4.145, 4.150, 4.155, 4.160, 4.165, 4.170, 4.175, 4.180, 4.185, 4.190, 4.195, 4.200, 4.205, 4.210, 4.215, 4.220, 4.225, 4.230, 4.235, 4.240, 4.245, 4.250, 4.255, 4.260, 4.265, 4.270, 4.275, 4.280, 4.285, 4.290, 4.295, 4.300, 4.305, 4.310, 4.315, 4.320, 4.325, 4.330, 4.335, 4.340, 4.345, 4.350, 4.355, 4.360, 4.365, 4.370, 4.375, 4.380, 4.385, 4.390, 4.395, 4.400, 4.405, 4.410, 4.415, 4.420, 4.425, 4.430, 4.435, 4.440, 4.445, 4.450, 4.455, 4.460, 4.465, 4.470, 4.475, 4.480, 4.485, 4.490, 4.495, 4.500, 4.505, 4.510, 4.515, 4.520, 4.525, 4.530, 4.535, 4.540, 4.545, 4.550, 4.555, 4.560, 4.565, 4.570, 4.575, 4.580, 4.585, 4.590, 4.595, 4.600, 4.605, 4.610, 4.615, 4.620, 4.625, 4.630, 4.635, 4.640, 4.645, 4.650, 4.655, 4.660, 4.665, 4.670, 4.675, 4.680, 4.685, 4.690, 4.695, 4.700, 4.705, 4.710, 4.715, 4.720, 4.725, 4.730, 4.735, 4.740, 4.745, 4.750, 4.755, 4.760, 4.765, 4.770, 4.775, 4.780, 4.785, 4.790, 4.795, 4.800, 4.805, 4.810, 4.815, 4.820, 4.825, 4.830, 4.835, 4.840, 4.845, 4.850, 4.855, 4.860, 4.865, 4.870, 4.875, 4.880, 4.885, 4.890, 4.895, 4.900, 4.905, 4.910, 4.915, 4.920, 4.925, 4.930, 4.935, 4.940, 4.945, 4.950, 4.955, 4.960, 4.965, 4.970, 4.975, 4.980, 4.985, 4.990, 4.995, 5.000, 5.005, 5.010, 5.015, 5.020, 5.025, 5.030, 5.035, 5.040, 5.045, 5.050, 5.055, 5.060, 5.065, 5.070, 5.075, 5.080, 5.085, 5.090, 5.095, 5.100, 5.105, 5.110, 5.115, 5.120, 5.125, 5.130, 5.135, 5.140, 5.145, 5.150, 5.155, 5.160, 5.165, 5.170, 5.175, 5.180, 5.185, 5.190, 5.195, 5.200, 5.205, 5.210, 5.215, 5.220, 5.225, 5.230, 5.235, 5.240, 5.245, 5.250, 5.255, 5.260, 5.265, 5.270, 5.275, 5.280, 5.285, 5.290, 5.295, 5.300, 5.305, 5.310, 5.315, 5.320, 5.325, 5.330, 5.335, 5.340, 5.345, 5.350, 5.355, 5.360, 5.365, 5.370, 5.375, 5.380, 5.385, 5.390, 5.395, 5.400, 5.405, 5.410, 5.415, 5.420, 5.425, 5.430, 5.435, 5.440, 5.445, 5.450, 5.455, 5.460, 5.465, 5.470, 5.475, 5.480, 5.485, 5.490, 5.495, 5.500, 5.505, 5.510, 5.515, 5.520, 5.525, 5.530, 5.535, 5.540, 5.545, 5.550, 5.555, 5.560, 5.565, 5.570, 5.575, 5.580, 5.585, 5.590, 5.595, 5.600, 5.605, 5.610, 5.615, 5.620, 5.625, 5.630, 5.635, 5.640, 5.645, 5.650, 5.655, 5.660, 5.665, 5.670, 5.675, 5.680, 5.685, 5.690, 5.695, 5.700, 5.705, 5.710, 5.715, 5.720, 5.725, 5.730, 5.735, 5.740, 5.745, 5.750, 5.755, 5.760, 5.765, 5.770, 5.775, 5.780, 5.785, 5.790, 5.795, 5.800, 5.805, 5.810, 5.815, 5.820, 5.825, 5.830, 5.835, 5.840, 5.845, 5.850, 5.855, 5.860, 5.865, 5.870, 5.875, 5.880, 5.885, 5.890, 5.895, 5.900, 5.905, 5.910, 5.915, 5.920, 5.925, 5.930, 5.935, 5.940, 5.945, 5.950, 5.955, 5.960, 5.965, 5.970, 5.975, 5.980, 5.985, 5.990, 5.995, 6.000, 6.005, 6.010, 6.015, 6.020, 6.025, 6.030, 6.035, 6.040, 6.045, 6.050, 6.055, 6.060, 6.065, 6.070, 6.075, 6.080, 6.085, 6.090, 6.095, 6.100, 6.105, 6.110, 6.115, 6.120, 6.125, 6.130, 6.135, 6.140, 6.145, 6.150, 6.155, 6.160, 6.165, 6.170, 6.175, 6.180, 6.185, 6.190, 6.195, 6.200, 6.205, 6.210, 6.215, 6.220, 6.225, 6.230, 6.235, 6.240, 6.245, 6.250, 6.255, 6.260, 6.265, 6.270, 6.275, 6.280, 6.285, 6.290, 6.295, 6.300, 6.305, 6.310, 6.315, 6.320, 6.325, 6.330, 6.335, 6.340, 6.345, 6.350, 6.355, 6.360, 6.365, 6.370, 6.375, 6.380, 6.385, 6.390, 6.395, 6.400, 6.405, 6.410, 6.415, 6.420, 6.425, 6.430, 6.435, 6.440, 6.445, 6.450, 6.455, 6.460, 6.465, 6.470, 6.475, 6.480, 6.485, 6.490, 6.495, 6.500, 6.505, 6.510, 6.515, 6.520, 6.525, 6.530, 6.535, 6.540, 6.545, 6.550, 6.555, 6.560, 6.565, 6.570, 6.575, 6.580, 6.585, 6.590, 6.595, 6.600, 6.605, 6.610, 6.615, 6.620, 6.625, 6.630, 6.635, 6.640, 6.645, 6.650, 6.655, 6.660, 6.665, 6.670, 6.675, 6.680, 6.685, 6.690, 6.695, 6.700, 6.705, | | |







THIS HARNESS IS FOR WIPERS, BACK-UP, HVAC ACCESSORY POWER FEED, AUX. BATTERY FEED, AND AUX. ACCESSORY FEED. IT WILL BE INSTALLED BETWEEN THE FORD WIPER CONNECTION UNDER THE HOOD, THE CHASSIS BATTERY, THE CHASSIS HEATER POWER SOURCE (JUST BEHIND THE BATTERY), THE WIPER/WASHER RESERVOIR, AND THE FORD COMMAND CENTER HARNESS IN THE LH TOEBORD AREA.

| CIRCUIT | DESCRIPTION | END POINTS | FUNCTION |
|---------|--------------|------------|-------------------|
| 000A | 14 BLU/GRY * | F, F1 | GROUND |
| 000B | 16 WHI * | E1, F1, G1 | GROUND |
| 004A | 16 BLU/WHI * | F, F1 | BACK-UP |
| 004B | 14/16 PNK * | A1, A2, F | BACK-UP |
| 103A | 14 RED * | F, F1 | WIPER POWER |
| 103B | 14 YEL * | A2, F | WIPER POWER |
| 111 | 16 PNK/BLK | A2, G1 | WASHER |
| 210 | 10 RED | K1, X2 | BATTERY (UNFUSED) |
| 211 | 10 RED/BLK | A2, K1 | BATT FEED #2 |
| 212 | 10 RED | J1, X2 | BATTERY (UNFUSED) |
| 213 | 10 YEL | E1, J1 | BATTERY (UNFUSED) |
| 214 | A2, E1 | A2, E1 | ACCY FEED #2 |
| 215 | 12 ORN/BLK | A2, H1 | HVAC FEED |
| 415A | 16 YEL * | F, F1 | ACCY SIGNAL |
| 415B | 16 GRY * | E1, F | ACCY SIGNAL |

- SEE NOTES

| | |
|--|-------------------------|
| PROPRIETARY This drawing and the information contained herein are the property of Morgan Olson and are not to be distributed, copied, or used by anyone other than Morgan Olson without the written consent of Morgan Olson. | |
| | |
| DIMENSION: STANDARD UNLESS OTHERWISE NOTED 1. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 2. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 3. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 4. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 5. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 6. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 7. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 8. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 9. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 10. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 11. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 12. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 13. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 14. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 15. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 16. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 17. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 18. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 19. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 20. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 21. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 22. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 23. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 24. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 25. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 26. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 27. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 28. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 29. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 30. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 31. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 32. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 33. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 34. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 35. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 36. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 37. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 38. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 39. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 40. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 41. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 42. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 43. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 44. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 45. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 46. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 47. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 48. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 49. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 50. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 51. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 52. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 53. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 54. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 55. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 56. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 57. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 58. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 59. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 60. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 61. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 62. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 63. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 64. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 65. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 66. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 67. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 68. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 69. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 70. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 71. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 72. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 73. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 74. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 75. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 76. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 77. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 78. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 79. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 80. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 81. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 82. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 83. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 84. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 85. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 86. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 87. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 88. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 89. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 90. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 91. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 92. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 93. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 94. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 95. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 96. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 97. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 98. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 99. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) 100. ANGLE 1/2" X 1/2" X 1/2" (SEE NOTE 1) | |
| ORDER ALL QUANTITY | QUANTITY 45/755 |
| DATE 12AUG15 | DATE 45/755 |
| DO NOT SCALE | |
| NAME HARN WPR/ENG E-SERIES NEW-STYLE WSHR BTL | |
| SHT 2 of 2 | DRAWING NO. 15508200 |
| SCALE NONE | SCALE NONE |
| REV 0 | REV 0 |





NOTES