

Accessing the Vehicle

Your new Morgan Olson Route Star van body includes 4 keys types.



Ignition Key



Side Door Key



Bulkhead & Rear
Door Key



Overhead
Compartment
Key

The position of the side door handle lock cylinder will indicate a locked or unlocked condition.

Pushed in - is the locked position.

Out - is the unlocked position.



Starting & Stopping

Starting

1. Tap fob button once.
2. Back light on Engine Start / Stop switches begin flashing.
This indicates that a Valid ID has been detected.
3. Within 5-seconds, press the Engine Start button once to initiate truck start sequence.
4. Press the Engine Start button a 2nd time to crank starter.
5. Release Engine Start button when engine turns over.
The truck is now in 'Run' mode.

(If **truck did not start**, the Engine Start button can be pressed again within 5-seconds of releasing the Engine Start button to try and re-crank the truck starter motor.)

Stopping

1. If the engine is running AND the truck is stopped, press the Engine Stop button.
2. The truck engine will turn off.
3. Press the Stop button again and the bulkhead door will open.



*** Bulkhead keyless latch may not automatically release fully when vehicle is parked on an uneven surface.*



Bulkhead Door Operation

1. Press and hold fob button.
2. Bulkhead door automatically opens and remains open until driver manually closes door.
3. Door automatically latches and locks when door closes.

*** Bulkhead keyless latch may not automatically release fully when vehicle is parked on an uneven surface.*

Manual Operation

1. From the Cab area, using the bulkhead door key, insert into the bulkhead lock and turn clockwise to manually release the bulkhead latch.
2. From the cargo area, use the thumb release and slide it away from door to release the bulkhead latch.





Rear Door Operation




- 1. Quickly double-tap the fob button.
- 2. Rear door unlocks for 8-seconds.
- 3. During the 8-seconds, unlatch the rear door and manually open it.
- 4. Rear door must be manually closed.
- 5. Door automatically latches and locks when door closes.

Manual Operation

- 1. Slide the thumb release plate away from the door.
- 2. Use the “D” loop handle in the center of the door to raise the door.



Vehicle Parts and Service documentation is available for download at www.morganolsonparts.com



Morgan Olson
Warranty Department
1801 S. Nottawa Rd. Sturgis, MI 49091
1-800-262-3437
Morgan Olson Parts Department
1-800-233-4823
www.morganolsonparts.com



QUICK START GUIDE

FOR THE ROUTE STAR
WALK-IN VAN BODIES